

Table of Contents

CHAPTER 3—WIRING METHODS AND MATERIALS.....249

ARTICLE 300—WIRING METHODS.....253

Part I. General Requirements253

300.1	Scope	253
300.3	Conductors	254
300.4	Protection Against Physical Damage.....	255
300.5	Underground Installations	258
300.6	Protection Against Corrosion and Deterioration	262
300.7	Raceways Exposed to Different Temperatures.....	263
300.8	Not Permitted in Raceways.....	264
300.9	Raceways in Wet Locations Above Grade.....	264
300.10	Electrical Continuity	264
300.11	Securing and Supporting.....	265
300.12	Mechanical Continuity.....	266
300.13	Splices and Pigtails.....	267
300.14	Length of Free Conductors.....	268
300.15	Boxes or Conduit Bodies.....	269
300.17	Raceway Sizing	271
300.18	Inserting Conductors in Raceways	273
300.19	Supporting Conductors in Vertical Raceways	274
300.20	Induced Currents in Ferrous Metal Enclosures and Raceways.....	274
300.21	Spread of Fire or Products of Combustion.....	275
300.22	Ducts, Plenums, and Other Air-Handling Spaces.....	276
300.23	Panels Designed to Allow Access	278
	Article 300—Practice Questions.....	279

ARTICLE 310—CONDUCTORS FOR GENERAL WIRING.....282

310.1	Scope	282
310.2	Conductors	282
310.3	Stranded Conductors.....	282
310.4	Conductors in Parallel	283
310.5	Minimum Size Conductors	285
310.8	Location.....	285
310.9	Corrosive Conditions	285
310.10	Insulation Temperature Limitation	285
310.12	Conductor Identification.....	286
310.13	Conductor Construction.....	286
310.15	Conductor Ampacity	287
	Article 310—Practice Questions.....	295

ARTICLE 312—CABINETS, CUTOUT BOXES, AND METER SOCKET ENCLOSURES.....296

312.1 Scope

Part I. Installation.....296

312.2	Damp or Wet Locations.....	296
312.3	Installed in Walls.....	297
312.4	Repairing Gaps	297

312.5	Enclosures.....	297
312.8	Used for Raceway and Splices.....	298
	Article 312—Practice Questions.....	299

ARTICLE 314—OUTLET, DEVICE, PULL AND JUNCTION BOXES; CONDUIT BODIES; AND HANDHOLE ENCLOSURES.....300

Part I. General.....300

314.1	Scope	300
314.3	Nonmetallic Boxes	300
314.4	Metal Boxes	300
314.5	Short-Radius Conduit Bodies	300

Part II. Installation.....301

314.15	Damp or Wet Locations.....	301
314.16	Number of 6 AWG and Smaller Conductors in Boxes and Conduit Bodies	301
314.17	Conductors That Enter Boxes or Conduit Bodies	305
314.20	Boxes Recessed in Walls or Ceilings	306
314.21	Repairing Gaps Around Boxes.....	307
314.22	Surface Extensions	307
314.23	Support of Boxes and Conduit Bodies.....	307
314.25	Covers and Canopies.....	309
314.27	Outlet Box.....	310
314.28	Boxes and Conduit Bodies for Conductors 4 AWG and Larger	310
314.29	Wiring to be Accessible.....	312
314.30	Handhole Enclosures	313
	Article 314—Practice Questions.....	315

ARTICLE 320—ARMORED CABLE (TYPE AC).....317

Part I. General.....317

320.1	Scope	317
320.2	Definition.....	317

Part II. Installation.....317

320.10	Uses Permitted.....	317
320.12	Uses Not Permitted.....	318
320.15	Exposed Work.....	318
320.17	Through or Parallel to Framing Members.....	318
320.23	In Accessible Attics or Roof Spaces	318
320.24	Bends	319
320.30	Securing and Supporting.....	319
320.40	Boxes and Fittings.....	320
320.80	Conductor Ampacities	320

Part III. Construction Specifications.....321

320.100	Construction	321
320.108	Equipment Grounding Conductor.....	321
	Article 320—Practice Questions.....	322

ARTICLE 330—METAL-CLAD CABLE (TYPE MC).....323

Part I. General.....323

Table of Contents

330.1	Scope	323	Part II. Installation	340	
330.2	Definition.....	323	340.10	Uses Permitted	340
Part II. Installation		323	340.12	Uses Not Permitted.....	340
330.10	Uses Permitted	323	340.24	Bends	341
330.12	Uses Not Permitted.....	324	340.80	Ampacity	341
330.17	Through or Parallel to Framing Members.....	324	340.112	Insulation.....	341
330.23	In Accessible Attics or Roof Spaces	325		Article 340—Practice Questions.....	342
330.24	Bends	325	ARTICLE 342—INTERMEDIATE METAL CONDUIT (TYPE IMC)	343	
330.30	Securing and Supporting.....	325	Part I. General	343	
330.40	Fittings.....	326	342.1	Scope	343
330.80	Conductor Ampacities	327	342.2	Definition.....	343
Part III. Construction Specifications		327	342.6	Listing Requirements	343
330.108	Equipment Grounding Conductor.....	327	Part II. Installation	343	
	Article 330—Practice Questions.....	328	342.10	Uses Permitted	343
ARTICLE 334—NONMETALLIC-SHEATHED CABLE (TYPES NM AND NMC)		329	342.14	Dissimilar Metals.....	344
Part I. General		329	342.20	Trade Size.....	344
334.1	Scope	329	342.22	Number of Conductors	344
334.2	Definition.....	329	342.24	Bends	344
334.6	Listed.....	329	342.26	Number of Bends (360°)	344
Part II. Installation		329	342.28	Reaming.....	344
334.10	Uses Permitted	329	342.30	Securing and Supporting.....	344
334.12	Uses Not Permitted.....	330	342.42	Couplings and Connectors.....	346
334.15	Exposed	331	342.46	Bushings.....	346
334.17	Through or Parallel to Framing Members.....	331		Article 342—Practice Questions.....	348
334.23	Attics and Roof Spaces	332	ARTICLE 344—RIGID METAL CONDUIT (TYPE RMC)	349	
334.24	Bends	333	Part I. General	349	
334.30	Securing and Supporting.....	333	344.1	Scope	349
334.80	Conductor Ampacity	334	344.2	Definition.....	349
Part III. Construction Specifications		335	344.6	Listing Requirements	349
334.100	Construction.....	335	Part II. Installation	349	
334.104	Conductors	335	344.10	Uses Permitted	349
334.108	Equipment Grounding Conductor.....	335	344.14	Dissimilar Metals.....	350
334.112	Insulation.....	335	344.20	Trade Size.....	350
	Article 334—Practice Questions.....	336	344.22	Number of Conductors.....	350
			344.24	Bends	350
ARTICLE 338—SERVICE-ENTRANCE CABLE (TYPES SE AND USE)		337	344.26	Number of Bends (360°)	350
Part I. General		337	344.28	Reaming.....	350
338.1	Scope	337	344.30	Securing and Supporting.....	350
338.2	Definitions	337	344.42	Couplings and Connectors.....	352
Part II. Installation		337	344.46	Bushings.....	352
338.10	Uses Permitted	337		Article 344—Practice Questions.....	354
338.12	Uses Not Permitted.....	338	ARTICLE 348—FLEXIBLE METAL CONDUIT (TYPE FMC)	355	
338.24	Bends	338	Part I. General	355	
	Article 338—Practice Questions.....	339	348.1	Scope	355
			348.2	Definition.....	355
			348.6	Listing Requirements	355
ARTICLE 340—UNDERGROUND FEEDER AND BRANCH-CIRCUIT CABLE (TYPE UF)		340	Part II. Installation	355	
Part I. General		340	348.10	Uses Permitted	355
340.1	Scope	340	348.12	Uses Not Permitted.....	355
340.2	Definition.....	340	348.20	Trade Size.....	355
340.6	Listing Requirements	340	348.22	Number of Conductors.....	356
			348.24	Bends	356

348.26 Number of Bends (360°) 356
 348.28 Trimming 356
 348.30 Securing and Supporting 356
 348.42 Fittings 357
 348.60 Grounding and Bonding 357
 Article 348—Practice Questions 359

ARTICLE 350—LIQUIDTIGHT FLEXIBLE METAL CONDUIT (TYPE LFMC) 360

Part I. General 360
 350.1 Scope 360
 350.2 Definition 360
 350.6 Listing Requirements 360
Part II. Installation 360
 350.10 Uses Permitted 360
 350.12 Uses Not Permitted 360
 350.20 Trade Size 360
 350.22 Number of Conductors 361
 350.24 Bends 361
 350.26 Number of Bends (360°) 361
 350.30 Securing and Supporting 361
 350.42 Fittings 362
 350.60 Grounding and Bonding 362
 Article 350—Practice Questions 364

ARTICLE 352—RIGID POLYVINYL CHLORIDE CONDUIT (TYPE PVC) 365

Part I. General 365
 352.1 Scope 365
 352.2 Definition 365
Part II. Installation 365
 352.10 Uses Permitted 365
 352.12 Uses Not Permitted 366
 352.20 Trade Size 367
 352.22 Number of Conductors 367
 352.24 Bends 367
 352.26 Number of Bends (360°) 367
 352.28 Trimming 367
 352.30 Securing and Supporting 367
 352.44 Expansion Fittings 368
 352.46 Bushings 369
 352.48 Joints 370
 352.60 Equipment Grounding Conductor 370
 Article 352—Practice Questions 371

ARTICLE 356—LIQUIDTIGHT FLEXIBLE NONMETALLIC CONDUIT (TYPE LFNC) 372

Part I. General 372
 356.1 Scope 372
 356.2 Definition 372
 356.6 Listing Requirement 372
Part II. Installation 372
 356.10 Uses Permitted 372
 356.12 Uses Not Permitted 373
 356.20 Trade Size 373

356.22 Number of Conductors 373
 356.24 Bends 373
 356.26 Number of Bends (360°) 373
 356.30 Securing and Supporting 373
 356.42 Fittings 374
 356.60 Equipment Grounding Conductor 374
 Article 356—Practice Questions 375

ARTICLE 358—ELECTRICAL METALLIC TUBING (TYPE EMT) 376

Part I. General 376
 358.1 Scope 376
 358.2 Definition 376
 358.6 Listing Requirement 376
Part II. Installation 376
 358.10 Uses Permitted 376
 358.12 Uses Not Permitted 377
 358.20 Trade Size 377
 358.22 Number of Conductors 377
 358.24 Bends 377
 358.26 Number of Bends (360°) 378
 358.28 Reaming and Threading 378
 358.30 Securing and Supporting 378
 358.42 Couplings and Connectors 379
 Article 358—Practice Questions 380

ARTICLE 362—ELECTRICAL NONMETALLIC TUBING (TYPE ENT) 381

Part I. General 381
 362.1 Scope 381
 362.2 Definition 381
Part II. Installation 381
 362.10 Uses Permitted 381
 362.12 Uses Not Permitted 383
 362.20 Trade Sizes 384
 362.22 Number of Conductors 384
 362.24 Bends 384
 362.26 Number of Bends (360°) 384
 362.28 Trimming 384
 362.30 Securing and Supporting 384
 362.46 Bushings 385
 362.48 Joints 385
 362.60 Equipment Grounding Conductor 385
 Article 362—Practice Questions 386

ARTICLE 376—METAL WIREWAYS 387

Part I. General 387
 376.1 Scope 387
 376.2 Definition 387
Part II. Installation 387
 376.10 Uses Permitted 387
 376.12 Uses Not Permitted 387
 376.21 Conductors—Maximum Size 387
 376.22 Number of Conductors and Ampacity 387
 376.23 Wireway Sizing 387
 376.30 Supports 389

Table of Contents

376.56	Splices, Taps, and Power Distribution Blocks.....	389
	Article 376—Practice Questions.....	390
ARTICLE 380—MULTIOUTLET ASSEMBLIES.....		
380.1	Scope.....	391
380.2	Uses.....	391
380.3	Through Partitions.....	391
	Article 380—Practice Questions.....	392
ARTICLE 386—SURFACE METAL RACEWAYS.....		
Part I. General.....		
386.1	Scope.....	393
386.2	Definition.....	393
386.6	Listing Requirements.....	393
Part II. Installation.....		
386.10	Uses Permitted.....	393
386.12	Uses Not Permitted.....	394
386.21	Size of Conductors.....	394
386.22	Number of Conductors.....	394
386.30	Securing and Supporting.....	394
386.56	Splices and Taps.....	394
386.60	Equipment Grounding Conductor.....	394
386.70	Separate Compartments.....	395
	Article 386—Practice Questions.....	396
ARTICLE 392—CABLE TRAYS.....		
Part I. General.....		
392.1	Scope.....	397
392.2	Definition.....	397
Part II. Installation.....		
392.3	Uses Permitted.....	397
392.4	Uses Not Permitted.....	398
392.6	Installation.....	399
392.7	Equipment Grounding Conductor.....	399
392.8	Cable Installation.....	400
392.9	Number of Multiconductor Cables in Cable Trays.....	400
392.11	Conductor Ampacity of Multiconductor Cables in Cable Trays.....	400
	Article 392—Practice Questions.....	401