

# Table of Contents

Introduction .....	xi	110.16 Arc-Flash Hazard Warning.....	32
About This Textbook.....	xiii	110.22 Identification of Disconnecting Means.....	32
How to Use the <i>National Electrical Code</i> .....	xv	<b>Part II. 600V, Nominal, or Less .....</b>	<b>33</b>
About the Author.....	xviii	110.26 Spaces About Electrical Equipment .....	33
About the Graphic Illustrator .....	xix	110.27 Guarding.....	39
Mike Holt Enterprises Team.....	xx	110.28 Enclosure Types.....	39
<b>ARTICLE 90—INTRODUCTION TO THE NATIONAL ELECTRICAL CODE.....</b>	<b>1</b>	<b>CHAPTER 1. GENERAL—PRACTICE QUESTIONS .....</b>	<b>40</b>
90.1 Purpose of the <i>NEC</i> .....	1	<b>CHAPTER 2—WIRING AND PROTECTION .....</b>	<b>51</b>
90.2 Scope of the <i>NEC</i> .....	2	<b>ARTICLE 200—USE AND IDENTIFICATION OF GROUNDED CONDUCTORS.....</b>	<b>53</b>
90.3 <i>Code</i> Arrangement.....	3	<b>Part I. General.....</b>	<b>53</b>
90.4 Enforcement.....	3	200.1 Scope .....	53
90.5 Mandatory Requirements and Explanatory Material .....	5	200.6 Grounded Conductor Identification .....	53
90.6 Formal Interpretations.....	5	<b>ARTICLE 230—SERVICES .....</b>	<b>55</b>
90.7 Examination of Equipment for Product Safety.....	5	<b>Part I. General.....</b>	<b>55</b>
<b>ARTICLE 90. INTRODUCTION—PRACTICE QUESTIONS .....</b>	<b>6</b>	230.1 Scope .....	55
<b>CHAPTER 1—GENERAL.....</b>	<b>9</b>	<b>Part IV. Service-Entrance Conductors.....</b>	<b>55</b>
<b>ARTICLE 100—DEFINITIONS .....</b>	<b>11</b>	230.43 Wiring Methods.....	55
Definitions.....	11	<b>Part V. Service Equipment—General .....</b>	<b>55</b>
<b>ARTICLE 110—REQUIREMENTS FOR ELECTRICAL INSTALLATIONS .....</b>	<b>23</b>	230.66 Listed as Suitable for Service Equipment .....	55
<b>Part I. General Requirements .....</b>	<b>23</b>	230.71 Number of Disconnects.....	56
110.1 Scope .....	23	230.82 Connected on Supply Side of the Service Disconnect.....	56
110.2 Approval of Conductors and Equipment.....	23	<b>ARTICLE 240—OVERCURRENT PROTECTION .....</b>	<b>57</b>
110.3 Examination, Identification, Installation, and Use of Equipment .....	23	<b>Part I. General.....</b>	<b>57</b>
110.5 Copper Conductors .....	24	240.1 Scope .....	57
110.6 Conductor Sizes.....	24	240.4 Protection of Conductors.....	58
110.7 Wiring Integrity .....	24	240.6 Standard Ampere Ratings .....	59
110.8 Suitable Wiring Methods .....	25	240.15 Ungrounded Conductors .....	59
110.9 Interrupting Protection Rating .....	25	240.21 Overcurrent Protection Location in Circuit .....	59
110.10 Circuit Impedance, Short-Circuit Current Rating, and Other Characteristics.....	26	240.24 Location of Overcurrent Devices .....	59
110.11 Deteriorating Agents .....	27	<b>Part III. Enclosures.....</b>	<b>61</b>
110.12 Mechanical Execution of Work .....	27	240.32 Damp or Wet Locations.....	61
110.13 Mounting and Cooling of Equipment.....	28	240.33 Vertical Position .....	61
110.14 Conductor Termination and Splicing.....	29		

<b>ARTICLE 250—GROUNDING AND BONDING</b> .....	63
<b>Part I. General</b> .....	63
250.1 Scope.....	63
250.2 Definitions.....	63
250.4 General Requirements for Grounding and Bonding.....	65
250.8 Termination of Grounding and Bonding Conductors.....	71
250.10 Protection of Fittings.....	71
250.12 Clean Surfaces.....	71
<b>Part II. System Grounding and Bonding</b> .....	71
250.24 Service Equipment—Grounding and Bonding.....	71
<b>Part III. Grounding Electrode System and Grounding Electrode Conductor</b> .....	73
250.52 Grounding Electrode Types.....	73
250.53 Grounding Electrode Installation Requirements.....	76
250.60 Lightning Protection Electrode.....	78
250.62 Grounding Electrode Conductor.....	79
250.64 Grounding Electrode Conductor Installation.....	79
250.66 Sizing Grounding Electrode Conductor.....	80
250.68 Termination to the Grounding Electrode.....	82
250.70 Grounding Electrode Conductor Termination Fittings.....	82
<b>Part V. Bonding</b> .....	83
250.90 General.....	83
250.92 Bonding Equipment for Services.....	83
250.96 Bonding Other Enclosures.....	84
250.97 Bonding Metal Parts for Circuits over 250V.....	85
250.102 Bonding Conductors and Jumpers.....	85
250.106 Lightning Protection System.....	86
<b>Part VI. Equipment Grounding and Equipment Grounding Conductors</b> .....	87
250.110 Fixed Equipment Connected by Permanent Wiring Methods—General.....	87
250.118 Types of Equipment Grounding Conductors.....	87
250.119 Identification of Equipment Grounding Conductors.....	90
250.120 Equipment Grounding Conductor Installation.....	90
250.122 Sizing Equipment Grounding Conductor.....	91
<b>Part VII. Methods of Equipment Grounding</b> .....	91
250.136 Equipment Considered Grounded.....	91
250.148 Continuity and Attachment of Equipment Grounding Conductors in Boxes.....	91
<b>VIII. Direct-Current Systems</b> .....	92
250.166 Sizing Grounding Electrode Conductor.....	92
250.169 Ungrounded Direct-Current Systems.....	92
<b>CHAPTER 2. WIRING AND PROTECTION—PRACTICE QUESTIONS</b> .....	93
<b>CHAPTER 3—WIRING METHODS AND MATERIALS</b> .....	105
<b>ARTICLE 300—WIRING METHODS</b> .....	109
<b>Part I. General</b> .....	109
300.1 Scope.....	109
300.3 Conductors.....	109
300.4 Protection Against Physical Damage.....	111
300.5 Underground Installations.....	113
300.6 Protection Against Corrosion and Deterioration.....	115
300.7 Raceways Exposed to Different Temperatures.....	116
300.8 Not Permitted in Raceways.....	117
300.9 Raceways in Wet Locations Above Grade.....	117
300.10 Electrical Continuity.....	117
300.11 Securing and Supporting.....	118
300.13 Splices and Pigtails.....	119
300.14 Length of Free Conductors.....	119
300.15 Boxes or Conduit Bodies.....	120
300.16 Raceway or Cable to Open or Concealed Wiring.....	122
300.17 Raceway Sizing.....	122
300.18 Inserting Conductors in Raceways.....	124
300.20 Induced Currents in Ferrous Metal Enclosures and Raceways.....	124
300.21 Spread of Fire or Products of Combustion.....	125
300.22 Wiring in Ducts Not for Air Handling, Fabricated Ducts for Environmental Air, and Other Spaces for Environmental Air (Plenums).....	126
<b>ARTICLE 310—CONDUCTORS FOR GENERAL WIRING</b> .....	129
<b>Part I. General</b> .....	129
310.1 Scope.....	129
<b>Part II. Installation</b> .....	129
310.10 Uses Permitted.....	129
310.15 Conductor Ampacity.....	131
<b>Part III. Construction Specifications</b> .....	136
310.104 Conductor Construction.....	136
310.106 Conductors.....	136
310.110 Conductor Identification.....	136
<b>ARTICLE 312—CABINETS, CUTOUT BOXES AND METER SOCKET ENCLOSURES</b> .....	137
312.1 Scope.....	137
<b>PART I. INSTALLATION</b> .....	137
312.2 Damp or Wet Locations.....	137
312.3 Installed in Walls.....	138
312.4 Repairing Gaps.....	138
312.5 Enclosures.....	138
312.8 Enclosures With Splices, Taps, and Feed-Through Conductors.....	138

## **ARTICLE 314—OUTLET, DEVICE, PULL AND JUNCTION BOXES; CONDUIT BODIES; AND HANDHOLE ENCLOSURES**..... 141

<b>Part I. Scope and General</b> .....	141
314.1 Scope.....	141
314.3 Nonmetallic Boxes.....	141
314.4 Metal Boxes.....	141
<b>Part II. Installation</b> .....	142
314.15 Damp or Wet Locations.....	142
314.16 Number of 6 AWG and Smaller Conductors in Boxes and Conduit Bodies.....	142
314.17 Conductors That Enter Boxes or Conduit Bodies.....	144
314.20 Boxes Recessed in Walls or Ceilings.....	144
314.21 Repairing Noncombustible Surfaces.....	144
314.23 Support of Boxes and Conduit Bodies.....	144
314.28 Boxes and Conduit Bodies for Conductors 4 AWG and Larger.....	146
314.29 Wiring to be Accessible.....	148
314.30 Handhole Enclosures.....	149

## **ARTICLE 330—METAL-CLAD CABLE (TYPE MC)**..... 151

<b>Part I. General</b> .....	151
330.1 Scope.....	151
330.2 Definition.....	151
<b>Part II. Installation</b> .....	151
330.10 Uses Permitted.....	151
330.12 Uses Not Permitted.....	152
330.17 Through or Parallel to Framing Members.....	152
330.23 In Accessible Attics or Roof Spaces.....	153
330.24 Bends.....	153
330.30 Securing and Supporting.....	153
330.40 Fittings.....	154
330.80 Conductor Ampacities.....	154
<b>Part III. Construction Specifications</b> .....	154
330.108 Equipment Grounding Conductor.....	154

## **ARTICLE 338—SERVICE-ENTRANCE CABLE (TYPES SE AND USE)**..... 155

<b>Part I. General</b> .....	155
338.1 Scope.....	155
338.2 Definitions.....	155
<b>Part II. Installation</b> .....	155
338.10 Uses Permitted.....	155
338.12 Uses Not Permitted.....	156
338.24 Bends.....	156

## **ARTICLE 342—INTERMEDIATE METAL CONDUIT (TYPE IMC)**..... 157

<b>Part I. General</b> .....	157
342.1 Scope.....	157
342.2 Definition.....	157
342.6 Listing Requirements.....	157
<b>Part II. Installation</b> .....	157
342.10 Uses Permitted.....	157
342.14 Dissimilar Metals.....	158
342.20 Trade Size.....	158
342.22 Number of Conductors.....	158
342.24 Bends.....	158
342.26 Number of Bends (360°).....	158
342.28 Reaming.....	158
342.30 Securing and Supporting.....	158
342.42 Couplings and Connectors.....	160
342.46 Bushings.....	160

## **ARTICLE 344—RIGID METAL CONDUIT (TYPE RMC)**..... 161

<b>Part I. General</b> .....	161
344.1 Scope.....	161
344.2 Definition.....	161
344.6 Listing Requirements.....	161
<b>Part II. Installation</b> .....	161
344.10 Uses Permitted.....	161
344.14 Dissimilar Metals.....	162
344.20 Trade Size.....	162
344.22 Number of Conductors.....	162
344.24 Bends.....	162
344.26 Number of Bends (360°).....	162
344.28 Reaming.....	162
344.30 Securing and Supporting.....	163
344.42 Couplings and Connectors.....	164
344.46 Bushings.....	165
<b>Part III. Construction Specifications</b> .....	165
344.130 Standard Lengths.....	165

## **ARTICLE 348—FLEXIBLE METAL CONDUIT (TYPE FMC)**..... 167

<b>Part I. General</b> .....	167
348.1 Scope.....	167
348.2 Definition.....	167
348.6 Listing Requirements.....	167
<b>Part II. Installation</b> .....	167
348.10 Uses Permitted.....	167
348.12 Uses Not Permitted.....	167
348.22 Number of Conductors.....	167
348.24 Bends.....	168
348.26 Number of Bends (360°).....	168

348.28 Trimming .....	168	<b>Part II. Installation</b> .....	181
348.30 Securing and Supporting.....	168	356.10 Uses Permitted .....	181
348.42 Fittings .....	168	356.12 Uses Not Permitted .....	181
348.60 Grounding and Bonding .....	168	356.20 Trade Size.....	182
<b>ARTICLE 350—LIQUIDTIGHT FLEXIBLE METAL CONDUIT (TYPE LFMC)</b> .....	171	356.22 Number of Conductors.....	182
<b>Part I. General</b> .....	171	356.24 Bends.....	182
350.1 Scope .....	171	356.26 Number of Bends (360°).....	182
350.2 Definition .....	171	356.30 Securing and Supporting.....	182
350.6 Listing Requirements .....	171	356.42 Fittings .....	183
<b>Part II. Installation</b> .....	171	356.60 Equipment Grounding Conductor.....	183
350.10 Uses Permitted .....	171	<b>ARTICLE 358—ELECTRICAL METALLIC TUBING (TYPE EMT)</b> .....	185
350.12 Uses Not Permitted .....	171	<b>Part I. General</b> .....	185
350.20 Trade Size.....	171	358.1 Scope .....	185
350.22 Number of Conductors.....	172	358.2 Definition .....	185
350.24 Bends.....	172	358.6 Listing Requirement.....	185
350.26 Number of Bends (360°).....	172	<b>Part II. Installation</b> .....	185
350.30 Securing and Supporting.....	172	358.10 Uses Permitted .....	185
350.42 Fittings .....	173	358.12 Uses Not Permitted .....	185
350.60 Grounding and Bonding .....	173	358.20 Trade Size.....	186
<b>ARTICLE 352—RIGID POLYVINYL CHLORIDE CONDUIT (TYPE PVC)</b> .....	175	358.22 Number of Conductors.....	186
<b>Part I. General</b> .....	175	358.24 Bends.....	186
352.1 Scope .....	175	358.26 Number of Bends (360°).....	186
352.2 Definition .....	175	358.28 Reaming and Threading.....	186
<b>Part II. Installation</b> .....	175	358.30 Securing and Supporting.....	187
352.10 Uses Permitted .....	175	358.42 Couplings and Connectors .....	187
352.12 Uses Not Permitted .....	176	<b>ARTICLE 376—METAL WIREWAYS</b> .....	189
352.20 Trade Size.....	177	<b>Part I. General</b> .....	189
352.22 Number of Conductors.....	177	376.1 Scope .....	189
352.24 Bends.....	177	376.2 Definition .....	189
352.26 Number of Bends (360°).....	177	<b>Part II. Installation</b> .....	189
352.28 Trimming .....	177	376.10 Uses Permitted .....	189
352.30 Securing and Supporting.....	177	376.12 Uses Not Permitted .....	189
352.44 Expansion Fittings.....	178	376.21 Conductors—Maximum Size .....	189
352.46 Bushings .....	179	376.22 Number of Conductors and Ampacity .....	189
352.48 Joints .....	179	376.23 Wireway Sizing .....	190
352.60 Equipment Grounding Conductor.....	179	376.30 Supports.....	190
<b>ARTICLE 356—LIQUIDTIGHT FLEXIBLE NONMETALLIC CONDUIT (TYPE LFNC)</b> .....	181	376.56 Splices, Taps, and Power Distribution Blocks.....	190
<b>Part I. General</b> .....	181	<b>ARTICLE 392—CABLE TRAYS</b> .....	193
356.1 Scope .....	181	<b>Part I. General</b> .....	193
356.2 Definition .....	181	392.1 Scope .....	193
356.6 Listing Requirement.....	181	392.2 Definition .....	193
		<b>Part II. Installation</b> .....	193
		392.10 Uses Permitted .....	193
		392.12 Uses Not Permitted .....	194

392.18 Cable Tray Installations .....	194
392.20 Cable and Conductor Installation.....	194
392.22 Number of Conductors or Cables .....	194
392.30 Securing and Supporting.....	195
392.46 Bushed Raceway .....	195
392.56 Cable Splices.....	195
392.60 Equipment Grounding Conductor.....	195
392.80 Ampacity of Conductors .....	196

<b>CHAPTER 3. WIRING METHODS AND MATERIALS— PRACTICE QUESTIONS</b> .....	197
--	-----

## **CHAPTER 4—EQUIPMENT FOR GENERAL USE**..... 223

<b>ARTICLE 400—FLEXIBLE CORDS AND FLEXIBLE CABLES</b> .....	225
400.1 Scope .....	225
400.3 Suitability .....	225
400.4 Types of Flexible Cords and Flexible Cables.....	225
400.7 Uses Permitted .....	225
400.8 Uses Not Permitted .....	226
400.10 Pull at Joints and Terminals .....	226
400.14 Protection from Damage .....	227
400.23 Equipment Grounding Conductor Identification.....	227

<b>ARTICLE 404—SWITCHES</b> .....	229
404.1 Scope .....	229
404.2 Switch Connections .....	229
404.3 Switch Enclosures .....	229
404.4 Damp or Wet Locations.....	229
404.6 Position of Knife Switches.....	230
404.7 Indicating.....	230
404.8 Accessibility and Grouping .....	230
404.11 Circuit Breakers Used as Switches.....	231
404.12 Grounding of Enclosures .....	231
404.15 Switch Marking.....	231

<b>ARTICLE 408—SWITCHBOARDS AND PANELBOARDS</b> .....	233
<b>Part I. General</b> .....	233
408.1 Scope .....	233
408.4 Field Identification .....	233
408.5 Clearance for Conductors Entering Bus Enclosures .....	234
408.7 Unused Openings.....	234
<b>Part III. Panelboards</b> .....	234
408.36 Overcurrent Protection of Panelboards .....	234
408.40 Equipment Grounding Conductor.....	235

<b>ARTICLE 480—STORAGE BATTERIES</b> .....	237
480.1 Scope .....	237
480.2 Definitions .....	237
480.3 Wiring and Equipment Supplied from Batteries.....	237
480.4 Overcurrent Protection for Prime Movers.....	237
480.5 Disconnecting Means.....	238
480.8 Racks and Trays.....	238
480.9 Battery Locations.....	238

<b>CHAPTER 4. EQUIPMENT FOR GENERAL USE— PRACTICE QUESTIONS</b> .....	241
---	-----

## **CHAPTER 6—SPECIAL EQUIPMENT**..... 245

<b>ARTICLE 690—SOLAR PHOTOVOLTAIC (PV) SYSTEMS</b> .....	247
<b>Part I. General</b> .....	247
690.1 Scope .....	247
690.2 Definitions .....	247
690.3 Other Articles .....	252
690.4 Installation.....	253
690.5 Ground-Fault Protection .....	254
690.6 Alternating-Current Modules .....	255
<b>Part II. Circuit Requirements</b> .....	255
690.7 Maximum Voltage .....	255
690.8 Circuit Sizing and Protection .....	259
690.9 Overcurrent Protection .....	266
690.10 Stand-Alone Systems.....	268
690.11 Arc-Fault Circuit Protection (Direct Current).....	268
<b>Part III. Disconnecting Means</b> .....	268
690.13 Disconnecting Means for Conductors.....	268
690.14 PV System Disconnecting Means .....	269
690.15 PV Equipment Disconnect .....	271
690.16 Disconnecting Means for Fuses .....	271
690.17 Disconnect Requirement.....	272
690.18 Installation and Service.....	273
<b>Part IV. Wiring Methods</b> .....	273
690.31 Wiring Methods.....	273
690.32 Component Interconnections .....	275
690.33 Connectors .....	276
690.34 Access to Boxes.....	276
690.35 Ungrounded Systems.....	276
<b>Part V. Grounding</b> .....	277
690.41 System Grounding .....	277
690.42 Point of System Grounding Connection.....	277
690.43 Equipment Grounding .....	277
690.45 Size of Equipment Grounding Conductors.....	279
690.46 Array Equipment Grounding Conductors .....	279

690.47 Grounding Electrode System .....	279	<b>CHAPTER 7—SPECIAL CONDITIONS</b> .....	299
690.48 Open Grounding Connection .....	282	<b>ARTICLE 705—INTERCONNECTED ELECTRIC POWER</b>	
690.49 Open Grounding Connection for Grounded Systems .....	282	<b>PRODUCTION SOURCES</b> .....	301
<b>Part VI. Marking</b> .....	282	<b>Part I. General</b> .....	301
690.53 Direct-Current PV Power Source .....	282	705.1 Scope .....	301
690.54 Interactive System .....	283	705.2 Definitions .....	301
690.55 PV Systems with Energy Storage .....	283	705.10 Directory .....	302
690.56 Identification of Power Sources .....	283	705.12 Point of Connection .....	302
<b>Part VII. Connection to Other Sources</b> .....	284	705.40 Loss of Primary Source .....	306
690.60 Interactive Systems .....	284	<b>Part II. Utility-Interactive Inverters</b> .....	307
690.61 Loss of Interactive System Power .....	284	705.100 Unbalanced Interconnections .....	307
690.63 Unbalanced Interconnections .....	284	<b>CHAPTER 7. SPECIAL CONDITIONS—PRACTICE</b>	
690.64 Point of Connection .....	284	<b>QUESTIONS</b> .....	308
<b>Part VIII. Storage Batteries</b> .....	284	<b>CHAPTER 8. FINAL EXAMS</b> .....	311
690.71 Installation .....	284	<b>INDEX</b> .....	335
690.72 Charge Control .....	284		
690.74 Battery Interconnections .....	285		
<b>CHAPTER 6. SPECIAL EQUIPMENT—</b>			
<b>PRACTICE QUESTIONS</b> .....	286		