

TABLE OF CONTENTS

About This Textbookxiv	110.22 Identification of Disconnecting Means83
Additional Products to Help You Learnxvii	110.24 Available Fault Current Marking84
How to Use the <i>National Electrical Code</i>1	110.25 Lockable Disconnecting Means85
Article 90—Introduction to the <i>National Electrical Code</i>7	Part II. 1000V, Nominal, or Less85
90.1 Scope7	110.26 Spaces Around Electrical Equipment85
90.2 Use and Application of the NEC.....7	110.27 Protection Against Physical Damage.....95
90.3 Code Arrangement.....11	110.28 NEMA Enclosure Types.....96
90.4 NEC Enforcement12	
90.5 Mandatory Requirements and Explanatory Material13	CHAPTER 2—WIRING AND PROTECTION97
90.7 Examination of Equipment for Safety14	Article 200—Use and Identification of Grounded Conductors99
CHAPTER 1—GENERAL RULES15	200.1 Scope100
Article 100—Definitions17	200.2 General.....100
Article 110—General Requirements for Electrical Installations63	200.4 Neutral Conductor.....100
Part I. General Requirements63	200.6 Identification of Neutral and Grounded Conductors.....101
110.1 Scope63	200.7 Use of White or Gray Color103
110.2 Approval of Conductors and Equipment.....64	200.10 Receptacle and Screw Shell Terminal104
110.3 Use of Equipment.....64	
110.5 Conductor Material66	Article 210—Branch Circuits105
110.6 Conductor Sizes66	Part I. General Provisions105
110.7 Wiring Integrity.....66	210.1 Scope105
110.8 Suitable Wiring Methods66	210.3 Other Articles.....105
110.9 Interrupting Rating of Overcurrent Protective Devices67	210.4 Multiwire Branch Circuits.....105
110.10 Equipment Short-Circuit Current Rating68	210.5 Conductor Identification.....109
110.11 Deteriorating Agents.....70	210.6 Branch-Circuit Voltage.....110
110.12 Mechanical Execution of Work70	210.7 Multiple Branch Circuits110
110.13 Mounting and Cooling of Equipment.....72	210.17 Guest Rooms and Guest Suites.....111
110.14 Conductor Termination and Splicing.....72	Part II. Branch-Circuit Ratings111
110.15 High-Leg Conductor Identification.....79	210.19 Conductor Sizing.....111
110.16 Arc-Flash Hazard Warning Label, Other Than Dwelling Units ..80	210.20 Overcurrent Protection115
110.17 Servicing and Maintenance of Equipment82	210.21 Receptacle Rating.....116
110.20 Reconditioned Equipment.....82	210.23 Multiple-Outlet Branch Circuits.....116
110.21 Hazard Markings.....83	Article 215—Feeders119
	215.1 Scope119
	215.2 Conductor Sizing.....120
	215.3 Overcurrent Protection Sizing.....124
	215.6 Feeder Equipment Grounding Conductor.....125
	215.10 Ground-Fault Protection of Equipment125

215.12	Conductor Identification.....	125	230.43	Wiring Methods.....	151
215.15	Barriers.....	127	230.46	Spliced and Tapped Connections.....	152
215.18	Surge Protection.....	127	230.50	Protection Against Physical Damage.....	152
Article 225—Outside Branch Circuits and Feeders.....			230.51	Cable Supports.....	153
Part I. General.....			230.53	Raceways to Drain.....	153
225.1	Scope.....	129	230.54	Overhead Service Locations.....	153
225.6	Minimum Conductor Size and Support.....	129	230.56	High-Leg Conductor Identification.....	154
225.17	Masts as Supports.....	131	Part V. Service Disconnect—General.....		155
225.18	Clearance for Overhead Conductors.....	131	230.62	Service Equipment—Barriers.....	155
225.19	Clearances from Buildings.....	132	230.66	Marking for Service Equipment.....	155
225.22	Raceways on Exterior Surfaces of Buildings.....	133	230.67	Surge Protection.....	156
225.26	Trees for Conductor Support.....	133	Part VI. Service Disconnect—Disconnecting Means.....		157
225.27	Raceway Seals.....	134	230.70	Service Disconnect Requirements.....	157
Part II. Buildings or Other Structures Supplied by a Feeder.....			230.71	Number of Service Disconnects.....	158
225.30	Number of Supplies.....	134	230.72	Grouping of Service Disconnects.....	159
225.31	Disconnecting Means.....	135	230.79	Rating of Disconnect.....	159
225.33	Maximum Number of Disconnects.....	136	230.82	Connected on Supply Side of the Service Disconnect.....	160
225.34	Grouping of Disconnects.....	136	230.85	Emergency (Shutoff) Disconnect.....	161
225.37	Identification of Multiple Supplies.....	136	Part VII. Service Conductor Overcurrent Protection.....		163
225.39	Rating of Disconnecting Means.....	136	230.90	Overload Protection—Where Required.....	163
225.41	Emergency (Shutoff) Disconnects.....	136	230.91	Location.....	164
225.42	Surge Protection.....	137	230.95	Ground-Fault Protection of Equipment.....	164
Article 230—Services.....			Article 240—Overcurrent Protection.....		165
230.1	Scope.....	139	Part I. General.....		166
Part I. General.....			240.1	Scope.....	166
230.2	Number of Services.....	141	240.3	Other Articles (Overcurrent Protection of Equipment).....	167
230.3	Not to Pass Through a Building.....	142	240.4	Overcurrent Protection of Conductors.....	167
230.6	Conductors Considered Outside a Building or Structure.....	142	240.5	Overcurrent Protection of Flexible Cords, Flexible Cables, and Fixture Wires.....	172
230.7	Service Conductors Separate from Other Conductors.....	142	240.6	Standard Ampere Ratings.....	172
230.8	Raceway Seals.....	143	240.10	Supplementary Conductor Overcurrent Protection.....	173
230.9	Clearances on Buildings.....	144	240.13	Ground-Fault Protection of Equipment.....	174
230.10	Vegetation as Support.....	144	240.15	Overcurrent Protective Device, Handle Ties.....	174
Part II. Overhead Service Conductors.....			Part II. Location of Overcurrent Protective Device.....		175
230.23	Overhead Service Conductor Size and Rating.....	145	240.21	Location of Overcurrent Protective Device in Circuit.....	175
230.24	Vertical Clearance for Overhead Service Conductors.....	145	240.22	Grounded-Phase Conductor on Overcurrent Device.....	182
230.26	Point of Attachment.....	146	240.24	Location of Overcurrent Protective Devices.....	182
230.27	Means of Attachment.....	147	Part III. Enclosures Containing Overcurrent Protective Devices.....		183
230.28	Service Masts as Support.....	147	240.33	Vertical Position, Enclosures.....	183
Part III. Underground Service Conductors.....			Part V. Plug Fuses, Fuseholders, and Adapters.....		183
230.30	Installation.....	148	240.51	Edison-Base Fuses.....	183
230.31	Underground Service Conductor Ampacity.....	148	Part VI. Cartridge Fuses and Fuseholders.....		184
230.32	Protection Against Damage.....	149	240.67	Arc-Energy Reduction—Fuses.....	184
Part IV. Service-Entrance Conductors.....			Part VII. Circuit Breakers.....		184
230.40	Number of Service-Entrance Conductor Sets.....	149	240.81	Indicating.....	184
230.42	Conductor Sizing.....	149	240.83	Markings.....	184

240.85	Applications	185
240.86	Series Ratings	186
240.87	Arc-Energy Reduction—Circuit Breakers	186
Article 242—Overvoltage Protection189		
Part I. General190		
242.1	Scope	190
Part II. Surge-Protective Devices (SPDs), 1000V or Less190		
242.6	Listing.....	190
242.8	Short-Circuit Current Rating.....	190
242.9	Indicating	191
242.12	Uses Not Permitted.....	191
242.13	Type 1 SPDs—Supply Side of Service Equipment	191
242.14	Type 2 SPDs—Feeder Circuits	192
242.20	Number Required.....	193
242.24	Routing of Surge-Protective Device Conductors	193
Article 250—Grounding and Bonding195		
Part I. General196		
250.1	Scope	196
250.4	Performance Requirements for Grounding and Bonding	197
Earth Shells201		
250.6	Objectionable Current.....	201
Objectionable Current202		
Dangers of Objectionable Current203		
250.8	Connection of Grounding and Bonding Conductors.....	204
250.10	Protection of Ground Clamps and Fittings	205
250.12	Clean Surfaces	205
Part II. System Grounding and Bonding205		
250.20	Systems Required to be Grounded	205
250.21	Ungrounded Systems	206
250.24	Service Grounding	206
250.28	Main Bonding Jumper and System Bonding Jumper.....	211
250.30	Transformer Separately Derived Systems.....	212
Generator Separately Derived Systems219		
250.32	Buildings Supplied by a Feeder	220
250.36	Impedance Grounded Systems—480V to 1000V.....	221
Part III. Grounding Electrode System and Grounding Electrode Conductor223		
250.50	Grounding Electrode System	223
250.52	Grounding Electrode Types	223
250.53	Grounding Electrode Installation	227
250.54	Auxiliary Grounding Electrodes	230
250.60	Lightning Protection Electrode	232
250.62	Grounding Electrode Conductor	232
250.64	Grounding Electrode Conductor Installation	232
250.66	Sizing Grounding Electrode Conductors.....	237
250.68	Grounding Electrode Conductor Connection to Grounding Electrodes	238
250.70	Grounding Electrode Conductor Termination Fittings.....	240
Part IV. Enclosure and Raceway241		
250.80	Service Raceways and Enclosures	241
250.86	Other than Service Enclosures and Raceways	242
Part V. Bonding242		
250.92	Bonding Metal Service Raceways and Enclosures	242
250.94	Bonding for Communications Systems	245
250.97	Bonding Metal Raceways and Metal Cables Containing 277V and 480V Circuits.....	246
250.98	Bonding Loosely Jointed Metal Raceways.....	247
250.100	Bonding in Hazardous (Classified) Locations	247
250.102	Bonding Jumper Sizing.....	247
250.104	Bonding of Piping Systems and Exposed Structural Metal ...	251
250.106	Lightning Protection Systems.....	254
Part VI. Equipment Grounding Conductors254		
250.109	Metal Enclosures, Effective Ground-Fault Current Path.....	254
250.114	Equipment Connected by Cord and Plug.....	254
250.118	Types of Equipment Grounding Conductors.....	255
250.119	Identification of Wire-Type Equipment Grounding Conductors	259
250.120	Equipment Grounding Conductor Installation.....	261
250.122	Sizing Wire-Type Equipment Grounding Conductors.....	261
Part VII. Equipment Grounding Conductor Connections264		
250.134	Equipment Connected by Permanent Wiring Methods	264
250.138	Cord-and-Plug-Connected	264
250.140	Frames of Ranges, Ovens, and Clothes Dryers.....	264
250.146	Connecting Receptacle Grounding Terminal to an Equipment Grounding Conductor.....	265
250.148	Continuity and Attachment of Equipment Grounding Conductors in Boxes.....	268
CHAPTER 3—WIRING METHODS AND MATERIALS271		
Article 300—General Requirements for Wiring Methods and Materials275		
Part I. General Requirements275		
300.1	Scope	275
300.3	Conductors	276
300.4	Protection Against Physical Damage	278
300.5	Underground Installations.....	281
300.6	Protection Against Corrosion.....	284
300.7	Raceways Exposed to Different Temperatures.....	285
300.9	Raceways in Wet Locations Above Grade	286
300.10	Electrical Continuity.....	286

300.11	Securing and Supporting	287	314.3	Nonmetallic Boxes	331	
300.12	Mechanical Continuity	288	314.4	Metal Boxes	332	
300.13	Mechanical and Electrical Continuity of Conductors— Splices and Pigtails	289	314.5	Screws or Other Fasteners	332	
300.14	Conductor Length at Boxes	291	Part II. Installation	332		
300.15	Boxes or Fittings, Splices and Terminations	291	314.15	Wet Locations	332	
300.17	Number and Size of Conductors in a Raceway	292	314.16	Outlet Box Sizing	332	
300.18	Raceway Installations	294	314.17	Cables That Enter Boxes	340	
300.19	Supporting Conductors in Vertical Raceways	295	314.20	Flush-Mounted Boxes	340	
300.20	Reducing Inductive Heating	295	314.21	Repairing Noncombustible Surfaces	341	
300.21	Spread of Fire or Products of Combustion	297	314.22	Surface Extensions	341	
300.22	Wiring in Ducts and Plenum Spaces	298	314.23	Securing Boxes	342	
300.23	Panels Designed to Allow Access	301	314.27	Box Requirements	345	
300.25	Exit Stair Towers	301	314.28	Pull Boxes, Junction Boxes, and Conduit Bodies	346	
			314.29	Wiring to be Accessible	349	
			314.30	Handhole Enclosures	349	
Article 310—Conductors for General Wiring		303	Article 320—Armored Cable (Type AC)			353
Part I. General		303	Part I. General			353
310.1	Scope	303	320.1	Scope	353	
310.3	Conductors, Minimum Size and Material	303	320.6	Listing Requirements	353	
Part II. Construction Specifications		305	Part II. Installation			353
310.4	Conductor Construction and Application	305	320.10	Uses Permitted	353	
310.6	Conductor Identification	307	320.12	Uses Not Permitted	354	
Part III. Installation		308	320.15	Exposed Work	354	
310.10	Uses Permitted	308	320.17	Through or Parallel to Framing Members	354	
310.12	Dwelling Services and Feeders	310	320.23	In Roof Spaces	355	
310.14	Ampacities for Conductors Rated 0V to 2000V	313	320.24	Bending Radius	355	
310.15	Ampacity Tables	314	320.30	Securing and Supporting	355	
310.16	Ampacities of Insulated Conductors	321	320.40	Boxes and Fittings	356	
			320.80	Conductor Ampacity	357	
Article 312—Cabinets, Cutout Boxes, and Meter Socket Enclosures		323	Part III. Construction Specifications			358
Part I. General		323	320.100	Construction	358	
312.1	Scope	323	320.108	Equipment Grounding Conductor	358	
312.2	Damp or Wet Locations	324				
312.3	Position in Walls	324	Article 330—Metal-Clad Cable (Type MC)			359
312.4	Repairing Gaps in Noncombustible Surfaces	325	Part I. General			359
312.5	Cable Termination to Enclosures	325	330.1	Scope	359	
312.6	Deflection of Conductors	326	330.6	Listing Requirements	359	
312.8	Overcurrent Device Enclosures	327	Part II. Installation			360
312.10	Screws or Other Fasteners	328	330.10	Uses Permitted	360	
Part II. Construction Specifications		328	330.12	Uses Not Permitted	361	
312.100	Enclosure Material	328	330.15	Exposed Work	361	
			330.17	Through or Parallel to Framing Members	361	
Article 314—Boxes, Conduit Bodies, and Handhole Enclosures		331	330.23	In Roof Spaces	361	
Part I. General		331	330.24	Bending Radius	362	
314.1	Scope	331	330.30	Securing and Supporting	362	
			330.80	Conductor Ampacities	363	

Part III. Construction Specifications	364	340.10 Uses Permitted.....	383
330.108 Equipment Grounding Conductor.....	364	340.12 Uses Not Permitted.....	384
Article 334—Nonmetallic-Sheathed Cable (Type NM)	365	340.24 Bends.....	384
Part I. General	365	340.80 Ampacity.....	384
334.1 Scope.....	365	Part III. Construction Specifications	385
334.6 Listing Requirements.....	366	340.108 Equipment Grounding Conductor.....	385
Part II. Installation	366	340.112 Insulation.....	385
334.10 Type NM Cable, Uses Permitted.....	366	Article 342—Intermediate Metal Conduit (IMC)	387
334.12 Uses Not Permitted.....	367	Part I. General	387
334.15 Exposed Work.....	368	342.1 Scope.....	387
334.17 Through or Parallel to Framing Members.....	369	342.6 Listing Requirements.....	387
334.19 Cables Entering Enclosures.....	370	Part II. Installation	388
334.23 Accessible Roof Spaces.....	370	342.10 Uses Permitted.....	388
334.24 Bending Radius.....	370	342.14 Dissimilar Metals.....	388
334.30 Securing and Supporting.....	370	342.20 Trade Size.....	388
334.40 Boxes and Fittings.....	371	342.22 Number of Conductors.....	388
334.80 Conductor Ampacity.....	371	342.24 Bends.....	389
Part III. Construction Specifications	373	342.28 Reaming.....	389
334.108 Equipment Grounding Conductor.....	373	342.30 Securing and Supporting.....	389
Article 336—Power and Control Tray Cable (Type TC)	375	342.42 Couplings and Connectors.....	391
Part I. General	375	342.46 Bushings.....	392
336.1 Scope.....	375	342.60 Equipment Grounding Conductor.....	392
336.6 Listing Requirements.....	376	Article 344—Rigid Metal Conduit (RMC)	393
Part II. Installation	376	Part I. General	393
336.10 Uses Permitted.....	376	344.1 Scope.....	393
336.12 Uses Not Permitted.....	377	344.6 Listing Requirements.....	393
336.24 Bending Radius.....	377	Part II. Installation	394
Article 338—Service-Entrance Cable (Types SE and USE)	379	344.10 Uses Permitted.....	394
Part I. General	379	344.14 Dissimilar Metals.....	394
338.1 Scope.....	379	344.20 Trade Size.....	395
338.6 Listing Requirements.....	379	344.22 Number of Conductors.....	395
Part II. Installation	380	344.24 Bends.....	395
338.10 Uses Permitted.....	380	344.28 Reaming and Threading.....	395
338.12 Uses Not Permitted.....	381	344.30 Securing and Supporting.....	395
338.24 Bending Radius.....	381	344.42 Couplings and Connectors.....	397
Article 340—Underground Feeder and Branch-Circuit Cable (Type UF)	383	344.46 Bushings.....	398
Part I. General	383	344.60 Equipment Grounding Conductor.....	398
340.1 Scope.....	383	Article 348—Flexible Metal Conduit (FMC)	399
340.6 Listing Requirements.....	383	Part I. General	399
Part II. Installation	383	348.1 Scope.....	399
		348.6 Listing Requirements.....	399
		Part II. Installation	399
		348.10 Uses Permitted.....	399
		348.12 Uses Not Permitted.....	400

348.20	Trade Size	400
348.22	Number of Conductors	401
348.24	Bends	401
348.28	Trimming	401
348.30	Securing and Supporting	402
348.42	Couplings and Connectors	403
348.60	Equipment Grounding and Bonding Conductors	403

Article 350—Liquidtight Flexible Metal Conduit (LFMC).....405

Part I. General

350.1	Scope	405
350.6	Listing Requirements	406

Part II. Installation

350.10	Uses Permitted.....	406
350.12	Uses Not Permitted.....	406
350.20	Trade Size	406
350.22	Number of Conductors	407
350.24	Bends	407
350.28	Trimming	407
350.30	Securing and Supporting	407
350.60	Equipment Grounding and Bonding Conductors	409

Article 352—Rigid Polyvinyl Chloride Conduit (PVC).....411

Part I. General

352.1	Scope	412
352.6	Listing.....	412

Part II. Installation

352.10	Uses Permitted.....	412
352.12	Uses Not Permitted.....	413
352.20	Trade Size	414
352.22	Number of Conductors	414
352.24	Bends	414
352.28	Trimming	415
352.30	Securing and Supporting	415
352.44	Expansion Fittings.....	416
352.46	Bushings	416
352.48	Joints.....	417
352.60	Equipment Grounding Conductor.....	417

Article 356—Liquidtight Flexible Nonmetallic Conduit (LFNC).....419

Part I. General

356.1	Scope	419
356.6	Listing Requirements	419

Part II. Installation

356.10	Uses Permitted.....	420
356.12	Uses Not Permitted.....	420

356.20	Trade Size	421
356.22	Number of Conductors	421
356.24	Bends	421
356.30	Securing and Supporting	421
356.42	Fittings	422
356.60	Equipment Grounding Conductor.....	422

Article 358—Electrical Metallic Tubing (EMT).....423

Part I. General

358.1	Scope	423
358.6	Listing Requirements	423

Part II. Installation

358.10	Uses Permitted.....	424
358.12	Uses Not Permitted.....	425
358.20	Trade Size	425
358.22	Number of Conductors	425
358.24	Bends	426
358.28	Reaming	426
358.30	Securing and Supporting	426
358.42	Couplings and Connectors.....	427
358.60	Equipment Grounding Conductor.....	428

Article 362—Electrical Nonmetallic Tubing (ENT).....429

Part I. General

362.1	Scope	429
362.6	Listing.....	430

Part II. Installation

362.10	Uses Permitted.....	430
362.12	Uses Not Permitted.....	431
362.20	Trade Sizes.....	432
362.22	Number of Conductors	432
362.24	Bends	432
362.28	Trimming	433
362.30	Securing and Supporting	433
362.46	Bushings	433
362.48	Joints.....	434
362.60	Equipment Grounding Conductor.....	434

Article 376—Metal Wireways.....435

Part I. General

376.1	Scope	435
-------	-------------	-----

Part II. Installation

376.10	Uses Permitted.....	435
376.12	Uses Not Permitted.....	436
376.20	Conductors Connected in Parallel.....	436
376.21	Size of Conductors.....	436
376.22	Number of Conductors and Ampacity	437

376.23	Wireway Sizing	438	400.10	Uses Permitted.....	458
376.30	Supports	439	400.12	Uses Not Permitted.....	460
376.56	Splices, Taps, and Power Distribution Blocks	439	400.13	Splices.....	461
376.60	Equipment Grounding Conductor.....	440	400.14	Pull at Joints and Terminals.....	461
Article 380—Multioutlet Assemblies.....		443	400.17	Protection from Damage	461
Part I. General		444	Article 402—Fixture Wires.....		
380.1	Scope	444	402.1	Scope	463
Part II. Installation		444	402.2	Other Articles.....	463
380.10	Uses Permitted.....	444	402.3	Types	463
380.12	Uses Not Permitted.....	444	402.5	Ampacity of Fixture Wires.....	463
380.76	Through Partitions.....	444	402.6	Minimum Size	463
Article 386—Surface Metal Raceways.....		445	402.7	Raceway Size.....	464
Part I. General		445	402.8	Neutral Conductor.....	464
386.1	Scope	445	402.10	Uses Permitted.....	464
386.6	Listing Requirements	446	402.12	Uses Not Permitted.....	464
Part II. Installation		446	Article 404—Switches.....		
386.10	Uses Permitted.....	446	Part I. Installation		465
386.12	Uses Not Permitted.....	446	404.1	Scope	465
386.21	Size of Conductors.....	446	404.3	Circuit Breaker Enclosures.....	466
386.22	Number of Conductors	446	404.4	Damp or Wet Locations	466
386.30	Securing and Supporting	447	404.7	Indicating	467
386.56	Splices and Taps	447	404.8	Accessibility and Grouping	467
386.60	Equipment Grounding Conductor.....	447	404.9	General-Use Snap Switches, Dimmers, and Control Switches	469
Article 392—Cable Trays.....		449	404.10	Mounting of Snap Switches, Dimmers, and Control Switches	470
Part I. General		449	404.12	Bonding of Enclosures.....	471
392.1	Scope	449	404.14	Rating and Use of Snap Switches	471
Part II. Installation		449	Part II. Construction Specifications.....		472
392.10	Uses Permitted.....	449	404.20	Switch Marking	472
392.12	Uses Not Permitted.....	451	Article 406—Receptacles, Attachment Plugs, and Flanged Inlets.....		
392.18	Cable Tray Installations	451	406.1	Scope	474
392.20	Cable and Conductor Installation	452	406.3	Receptacle Rating and Type	474
392.30	Securing and Supporting	452	406.4	General Installation Requirements.....	475
392.44	Expansion Splice Plates	452	406.5	Receptacle Mounting.....	475
392.46	Bushed Conduit and Tubing.....	452	406.6	Receptacle Faceplates	478
392.56	Cable Splices.....	453	406.7	Attachment Plugs and Flanged Surface Inlets	478
392.60	Equipment Grounding Conductor.....	453	406.9	Receptacles in Damp or Wet Locations.....	478
CHAPTER 4—EQUIPMENT FOR GENERAL USE.....		455	406.11	Connecting Receptacle Grounding Terminal to Equipment Grounding Conductor	481
Article 400—Flexible Cords.....		457	406.12	Tamper-Resistant Receptacles.....	481
400.1	Scope	457			
400.3	Suitability	457			
400.4	Types of Flexible Cords.....	458			
400.5	Ampacity of Flexible Cords.....	458			

Article 408—Switchboards and Panelboards	483
Part I. General	484
408.1 Scope	484
408.3 Arrangement of Busbars and Conductors.....	484
408.4 Circuit Directory and Description	485
408.5 Clearance for Conductors Entering Bus Enclosures	487
408.6 Short-Circuit Current Rating.....	487
408.7 Unused Openings	487
408.9 Replacement Panelboards	487
Part II. Switchboards	487
408.18 Clearances	487
Part III. Panelboards	488
408.30 Panelboard Rating.....	488
408.36 Overcurrent Protection	488
408.37 Panelboards in Damp or Wet Locations	489
408.38 Enclosure	489
408.40 Equipment Grounding Conductor.....	489
408.41 Neutral Conductor Terminations	489
408.43 Panelboard Orientation.....	490
 Article 445—Generators	491
445.1 Scope	491
445.6 Listing.....	492
445.11 Marking.....	492
445.13 Conductor Ampacity.....	492
445.18 Disconnecting Means	493
445.19 Emergency Shutdown of Prime Mover	493
 Article 450—Transformers	495
450.1 Scope	495
450.3 Primary Overcurrent Protection.....	496
450.9 Ventilation	498
450.10 Grounding and Bonding.....	498
450.13 Transformer Accessibility.....	498
450.14 Disconnecting Means	499
 Article 480—Stationary Standby Batteries	501
480.1 Scope	501
480.4 Battery and Cell Terminations	502
480.9 Battery Support Systems.....	503
480.10 Battery Locations.....	503
480.12 Battery Interconnections.....	504
 EXAM A	
STRAIGHT ORDER—ARTICLES 90–480	505

CHAPTER 6—SPECIAL EQUIPMENT	515
Article 625—Electric Vehicle Power Transfer System	517
Part I. General	517
625.1 Scope	517
625.6 Listed.....	517
Part III. Installation	518
625.40 Electric Vehicle Branch Circuit.....	518
625.41 Overcurrent Protection	519
625.42 Load.....	520
625.43 Disconnecting Means	521
625.48 Interactive Equipment	521
625.49 Island Mode	521
625.52 Ventilation	522
625.54 GFCI	522
Part IV. Wireless Power Transfer Equipment	522
625.101 Grounding	522
625.102 Installation	523
 Article 690—Solar Photovoltaic (PV) Systems	525
Part I. General	525
690.1 Scope	525
690.4 General Requirements.....	526
690.6 Alternating-Current Modules	529
Part II. Circuit Requirements	530
690.7 Maximum PV System Direct-Current Circuit Voltage	530
690.8 Circuit Current and Conductor Sizing.....	535
690.9 Overcurrent Protection	544
690.11 Arc-Fault Circuit Protection	546
690.12 Rapid Shutdown—PV Circuits on Building	546
Part III. Disconnect	551
690.13 PV System Disconnect	551
690.15 PV Equipment Disconnect/Isolating Device.....	553
Part IV. Wiring Methods	555
690.31 Wiring Methods and Materials.....	555
690.32 Component Interconnections	559
690.33 Connectors (Mating).....	560
690.34 Access to Boxes	561
Part V. Grounding and Bonding	561
690.41 PV System DC Circuit Grounding and Protection.....	561
690.43 Equipment Grounding Conductor.....	562
690.45 Size of Equipment Grounding Conductors	563
690.47 Grounding Electrode System	564
Part VI. Source Connections	565
690.56 Identification of Power Sources.....	565
690.59 Connection to Other Power Sources	565

Article 691—Large-Scale Photovoltaic (PV) Electric Supply Stations567

691.1	Scope	567
691.4	Special Requirements for Large-Scale PV Electric Supply Stations	567
691.5	Equipment.....	568
691.6	Engineered Design.....	568
691.7	Conformance of Construction to Engineered Design.....	568
691.8	Direct-Current Operating Voltage	568
691.9	Disconnect for Isolating Photovoltaic Equipment.....	568
691.10	Fire Mitigation.....	569
691.11	Fence Bonding and Grounding	569

CHAPTER 7—SPECIAL CONDITIONS571

Article 702—Optional Standby Systems573

Part I. General		573
702.1	Scope	573
702.4	Capacity and Rating.....	574
702.5	Interconnection Equipment or Transfer Equipment	575
702.7	Signs.....	576
Part II. Circuit Wiring.....		577
702.10	Wiring.....	577
702.12	Outdoor Generators	577

Article 705—Interconnected Electric Power Production Sources579

Part I. General		579
705.1	Scope	579
705.6	Equipment Approval	580
705.8	System Installation	581
705.10	Identification of Parallel Power Production Sources.....	582
705.11	Service Connection.....	583
705.12	Load-Side Source Connection	585
705.13	Energy Management Systems.....	590
705.20	Power Production Source Disconnect.....	591
705.25	Wiring Methods	592
705.28	Output Current and Circuit Sizing.....	593
705.30	Overcurrent Protection	594
705.32	Ground-Fault Protection	596
705.40	Loss of Primary Source	596
705.45	Unbalanced Interconnections.....	597
Part II. Microgrid Systems		597
705.50	Microgrid System Operation.....	597
705.60	Connections to the Primary Source	598
705.70	Microgrid Interconnect Devices (MID).....	598
705.76	Microgrid Control System (MCS)	599

Article 706—Energy Storage Systems601

Part I. General		601
706.1	Scope	601
706.3	Qualified Personnel.....	602
706.4	System Nameplate Requirements	602
706.5	Listing.....	603
706.6	Multiple Systems.....	603
706.7	Commissioning and Maintenance	603
Part II. Disconnect		604
706.15	Disconnect.....	604
706.16	ESS in Parallel with Other Sources of Power	607
Part III. Installation Requirements.....		607
706.20	General Installation Requirements.....	607
Part IV. Energy Storage System Circuit Requirements		608
706.30	Circuit Current Rating	608
706.31	Overcurrent Protection	609

Article 710—Stand-Alone Systems.....611

710.1	Scope	611
710.6	Equipment Approval	611
710.10	Identification of Power Sources.....	611
710.12	Stand-Alone Inverter Input Circuit Current	612
710.15	Wiring.....	612

Article 750—Energy Management Systems613

750.1	Scope	613
750.6	Listing.....	613
750.20	Alternate Power Sources	614
750.30	Load Management.....	614
750.50	Directory	615

EXAM B

STRAIGHT ORDER—ARTICLES 625–750617

FINAL EXAM

RANDOM ORDER—ARTICLES 90–750627

INDEX.....639

About the Author648

About the Illustrator649

About the Mike Holt Team650