

TABLE OF CONTENTS

About This Textbook.....xv

Additional Products to Help You Learn.....xviii

How to Use the *National Electrical Code*..... 1

Article 90—Introduction to the *National Electrical Code*..... 7

90.1 Purpose of the *NEC*..... 7
 90.2 Scope of the *NEC* 8
 90.3 *Code* Arrangement.....10
 90.4 Enforcement11
 90.5 Mandatory Requirements and Explanatory Material13
 90.7 Examination of Equipment for Product Safety..... 14

CHAPTER 1—GENERAL RULES 15

Article 100—Definitions..... 17

100 Definitions 17

Article 110—Requirements for Electrical Installations.....45

Part I. General Requirements.....45

110.1 Scope45
 110.2 Approval of Conductors and Equipment.....45
 110.3 Use and Product Listing (Certification) of Equipment.....46
 110.4 Voltage Rating of Electrical Equipment46
 110.5 Conductor Material46
 110.6 Conductor Sizes46
 110.7 Wiring Integrity.....47
 110.8 Suitable Wiring Methods.....47
 110.9 Interrupting Rating (Overcurrent Protective Devices).....47
 110.10 Equipment Short-Circuit Current Rating.....48
 110.11 Deteriorating Agents.....49
 110.12 Mechanical Execution of Work50
 110.13 Mounting and Cooling of Equipment.....52
 110.14 Conductor Termination and Splicing.....52
 110.15 High-Leg Conductor Identification.....59
 110.16 Arc Flash Hazard Warning.....59
 110.21 Markings61
 110.22 Identification of Disconnecting Means62
 110.24 Available Fault Current63
 110.25 Lockable Disconnecting Means63

Part II. 1,000V, Nominal, or Less.....63

110.26 Spaces About Electrical Equipment.....63
 110.28 Enclosure Types72

CHAPTER 2—WIRING AND PROTECTION.....73

Article 200—Use and Identification of Grounded Conductors.....75

200.1 Scope76
 200.2 General.....76
 200.4 Neutral Conductor.....76
 200.6 Identification of Grounded Conductors.....77
 200.7 Use of White or Gray Color79

Article 210—Branch Circuits.....81

Part I. General Provisions.....81

210.1 Scope81
 210.4 Multiwire Branch Circuits82
 210.5 Identification for Branch Circuits.....84
 210.7 Multiple Branch Circuits85

Part II. Branch-Circuit Ratings.....86

210.18 Branch-Circuit Rating.....86
 210.19 Conductor Sizing86
 210.20 Overcurrent Protection88
 210.21 Receptacle Rating.....89
 210.23 Permissible Loads, Multiple-Outlet Branch Circuits90

Article 215—Feeders.....91

215.1 Scope91
 215.2 Conductor Sizing.....92
 215.3 Overcurrent Protection Sizing.....96
 215.10 Ground-Fault Protection of Equipment97
 215.12 Conductor Identification.....97

Article 225—Outside Branch Circuits and Feeders.....99

Part I. General.....99

225.1 Scope99
 225.6 Minimum Conductor Size and Support.....99
 225.16 Attachment of Overhead Conductors100
 225.17 Masts as Supports.....100

225.18 Clearance for Overhead Conductors..... 101

225.19 Clearances from Buildings 102

225.22 Raceways on Exterior Surfaces of Buildings or Other Structures 103

225.26 Trees for Conductor Support 103

225.27 Raceway Seals 104

Part II. Buildings or Other Structures Supplied by a Feeder..... 104

225.30 Number of Supplies 104

225.31 Disconnecting Means 105

225.32 Disconnecting Means Location 105

225.33 Maximum Number of Disconnects..... 105

225.34 Grouping of Disconnects 106

225.37 Identification of Multiple Supplies 106

225.39 Rating of Disconnecting Means..... 106

Article 230—Services 107

Part I. General 107

230.1 Scope 107

230.2 Number of Services 107

230.3 Not to Pass Through a Building 109

230.6 Conductors Considered Outside a Building..... 109

230.7 Service Conductors Separate from Other Conductors 109

230.8 Raceway Seals 110

230.9 Clearances on Buildings..... 110

230.10 Vegetation as Support..... 110

Part II. Overhead Service Conductors 111

230.23 Overhead Service Conductor Size and Rating 111

230.24 Vertical Clearance for Overhead Service Conductors..... 112

230.26 Point of Attachment..... 112

230.27 Means of Attachment 113

230.28 Service Masts as Support..... 113

Part III. Underground Service Conductors..... 114

230.30 Installation 114

230.31 Underground Service Conductor Size and Rating 114

230.32 Protection Against Damage 114

Part IV. Service-Entrance Conductors 115

230.40 Number of Service-Entrance Conductor Sets..... 115

230.42 Conductor Sizing 115

230.43 Wiring Methods 119

230.46 Spliced Conductors..... 119

230.50 Protection Against Physical Damage 120

230.51 Cable Supports..... 120

230.53 Raceways to Drain 121

230.54 Overhead Service Locations 121

230.56 High-Leg Conductor Identification..... 122

Part V. Service Disconnect—General..... 122

230.62 Service Equipment—Enclosed or Guarded 122

230.66 Marking for Service Disconnect 123

230.67 Surge Protection 123

Part VI. Service Disconnect—Disconnecting Means 124

230.70 Service Disconnect Requirements..... 124

230.71 Number of Service Disconnects 125

230.72 Grouping of Disconnects 125

230.76 Manually or Power Operated 126

230.79 Rating of Disconnect 126

230.82 Connected on Supply Side of the Service Disconnect..... 126

230.85 Emergency Disconnects..... 128

Part VII. Service Disconnect Overcurrent Protection..... 128

230.90 Overload Protection—Where Required..... 128

230.91 Location 129

230.95 Ground-Fault Protection of Equipment 129

Article 240—Overcurrent Protection..... 131

Part I. General 132

240.1 Scope 132

240.2 Definitions 132

240.3 Other Articles (Overcurrent Protection of Equipment)..... 133

240.4 Overcurrent Protection of Conductors..... 133

240.5 Protection of Flexible Cords, Flexible Cables, and Fixture Wires 137

240.6 Standard Ampere Ratings..... 137

240.10 Supplementary Overcurrent Protection..... 138

240.13 Ground-Fault Protection of Equipment 138

240.15 Phase Conductor Overcurrent Device..... 139

Part II. Location..... 140

240.21 Location in Circuit 140

240.24 Location of Overcurrent Protective Devices at Premises 145

Part III. Enclosures 147

240.33 Vertical Position 147

Part IV. Disconnecting and Guarding..... 147

240.40 Disconnecting Means for Fuses 147

Part V. Plug Fuses, Fuseholders, and Adapters..... 147

240.51 Edison-Base Fuses 147

Part VI. Cartridge Fuses and Fuseholders 148

240.60 General..... 148

240.67 Arc Energy Reduction—Fuses..... 149

Part VII. Circuit Breakers..... 149

240.81 Indicating 149

240.83 Markings 149

240.85 Applications 150

240.86 Series Ratings 151

240.87 Arc Energy Reduction—Circuit Breakers 152

240.88 Reconditioned Equipment..... 153

Article 250—Grounding and Bonding..... 155

Part I. General 155

250.1 Scope 155

250.4 Performance Requirements for Grounding and Bonding 156

| | | | | | |
|---|---|-----|--|--|-----|
| 250.6 | Objectionable Current..... | 162 | Part VII. Methods of Equipment Grounding Conductor Connections | 226 | |
| 250.8 | Connection of Grounding and Bonding Connectors..... | 166 | 250.134 | Equipment Connected by Permanent Wiring Methods..... | 226 |
| 250.10 | Protection of Ground Clamps and Fittings | 166 | 250.136 | Equipment Secured to Grounded Metal Supports | 227 |
| 250.12 | Clean Surfaces | 166 | 250.138 | Cord-and-Plug-Connected | 227 |
| Part II. System Grounding and Bonding | | 167 | 250.140 | Frames of Ranges, Ovens, and Clothes Dryers..... | 227 |
| 250.20 | Systems Required to be Grounded | 167 | 250.142 | Neutral Conductor for Effective Ground-Fault Current Path | 228 |
| 250.21 | Ungrounded Systems | 168 | 250.146 | Connecting Receptacle Grounding Terminal to an Equipment Grounding Conductor..... | 229 |
| 250.24 | Grounding | 168 | 250.148 | Continuity and Attachment of Equipment Grounding Conductors in Boxes..... | 232 |
| 250.25 | Grounding for Supply Side of the Service Disconnect | 172 | | | |
| 250.28 | Main Bonding Jumper and System Bonding Jumper..... | 173 | CHAPTER 3—WIRING METHODS AND MATERIALS | 235 | |
| 250.30 | Separately Derived Systems..... | 174 | Article 300—General Requirements for Wiring Methods and Materials | 239 | |
| 250.32 | Buildings Supplied by a Feeder | 183 | Part I. General Requirements | 239 | |
| 250.34 | Generators—Portable and Vehicle- or Trailer-Mounted | 185 | 300.1 | Scope | 239 |
| 250.36 | High-Impedance Grounded Systems..... | 186 | 300.3 | Conductors | 240 |
| Part III. Grounding Electrode System and Grounding Electrode Conductor | | 186 | 300.4 | Protection Against Physical Damage..... | 243 |
| 250.50 | Grounding Electrode System | 186 | 300.5 | Underground Installations..... | 246 |
| 250.52 | Grounding Electrode Types | 187 | 300.6 | Protection Against Corrosion and Deterioration..... | 250 |
| 250.53 | Grounding Electrode Installation Requirements..... | 190 | 300.7 | Raceways Exposed to Different Temperatures..... | 251 |
| 250.54 | Auxiliary Grounding Electrodes | 195 | 300.9 | Raceways in Wet Locations Above Grade | 251 |
| 250.58 | Common Grounding Electrode | 196 | 300.10 | Electrical Continuity..... | 252 |
| 250.62 | Grounding Electrode Conductor | 196 | 300.11 | Securing and Supporting | 252 |
| 250.64 | Grounding Electrode Conductor Installation | 196 | 300.12 | Mechanical Continuity..... | 254 |
| 250.66 | Sizing Grounding Electrode Conductor..... | 200 | 300.13 | Mechanical and Electrical Continuity of Conductors- Splices and Pigtails..... | 255 |
| 250.68 | Grounding Electrode Conductor and Bonding Jumper Connection to Grounding Electrodes..... | 201 | 300.14 | Length of Free Conductors | 256 |
| 250.70 | Grounding Electrode Conductor Termination Fittings..... | 203 | 300.15 | Boxes or Fittings | 257 |
| Part IV. Enclosure, Raceway, and Service Cable Connections | | 204 | 300.17 | Number and Size of Conductors in a Raceway..... | 259 |
| 250.80 | Service Raceways and Enclosures | 204 | 300.18 | Inserting Conductors in Raceways | 261 |
| 250.86 | Other Enclosures..... | 204 | 300.19 | Supporting Conductors in Vertical Raceways..... | 261 |
| Part V. Bonding for Fault Current | | 204 | 300.20 | Induced Alternating Currents in Ferrous Metal Parts | 262 |
| 250.90 | General..... | 204 | 300.21 | Spread of Fire or Products of Combustion | 264 |
| 250.92 | Bonding Equipment Containing Service Conductors | 204 | 300.22 | Wiring in Ducts and Plenum Spaces..... | 265 |
| 250.94 | Bonding Communications Systems | 207 | 300.23 | Panels Designed to Allow Access | 267 |
| 250.96 | Bonding Other Enclosures..... | 208 | 300.25 | Exit Enclosures (Stair Towers)..... | 267 |
| 250.97 | Bonding Metal Parts Containing 277V and 480V Circuits | 209 | Article 310—Conductors for General Wiring | 269 | |
| 250.98 | Bonding Loosely Jointed Metal Raceways..... | 209 | Part I. General | 269 | |
| 250.102 | Neutral Conductor, Bonding Conductors, and Bonding Jumpers | 210 | 310.1 | Scope | 269 |
| 250.104 | Bonding of Piping Systems and Exposed Structural Metal | 212 | 310.3 | Conductors | 269 |
| 250.106 | Lightning Protection Systems..... | 216 | Part II. Construction Specifications | 270 | |
| Part VI. Equipment Grounding and Equipment Grounding Conductors | | 216 | 310.4 | Conductor Construction and Application | 270 |
| 250.109 | Metal Enclosures..... | 216 | 310.6 | Conductor Identification..... | 273 |
| 250.114 | Equipment Connected by Cord and Plug..... | 216 | | | |
| 250.118 | Types of Equipment Grounding Conductors..... | 218 | | | |
| 250.119 | Identification of Equipment Grounding Conductors | 221 | | | |
| 250.120 | Equipment Grounding Conductor Installation..... | 222 | | | |
| 250.121 | Restricted Use of Equipment Grounding Conductors | 223 | | | |
| 250.122 | Sizing Equipment Grounding Conductors..... | 223 | | | |

Part III. Installation273

310.10 Uses Permitted.....273

310.12 Single-Phase Dwelling Services and Feeders.....276

310.14 Ampacities for Conductors Rated 0V to 2,000V279

310.15 Ampacity Tables.....280

310.16 Ampacities of Insulated Conductors in Raceways, Cables,
or Buried287

Article 312—Cabinets289

Part I. Scope and Installation289

312.1 Scope289

312.2 Damp or Wet Locations289

312.3 Position in Walls290

312.4 Repairing Gaps in Noncombustible Surfaces290

312.5 Enclosures290

312.6 Deflection of Conductors.....292

312.8 Overcurrent Device Enclosures292

Part II. Construction Specifications.....294

312.10 Material294

**Article 314—Outlet, Pull, and Junction Boxes;
Conduit Bodies; and Handhole Enclosures**295

Part I. Scope and General295

314.1 Scope295

314.3 Nonmetallic Boxes295

314.4 Metal Boxes296

Part II. Installation296

314.15 Damp or Wet Locations296

314.16 Sizing Outlet Boxes296

314.17 Conductors That Enter Boxes or Conduit Bodies304

314.20 Flush-Mounted Box Installations304

314.21 Repairing Noncombustible Surfaces305

314.22 Surface Extensions306

314.23 Support of Boxes.....306

314.25 Covers and Canopies308

314.27 Outlet Box Requirements309

314.28 Sizing Pull and Junction Boxes.....311

314.29 Wiring to be Accessible.....314

314.30 Handhole Enclosures315

Article 320—Armored Cable (Type AC)317

Part I. General317

320.1 Scope317

320.2 Definition.....317

320.6 Listing Requirements317

Part II. Installation318

320.10 Uses Permitted.....318

320.12 Uses Not Permitted.....318

320.15 Exposed Work.....318

320.17 Through or Parallel to Framing Members.....318

320.23 In Accessible Attics or Roof Spaces319

320.24 Bending Radius319

320.30 Securing and Supporting319

320.40 Boxes and Fittings.....321

320.80 Conductor Ampacity.....321

Part III. Construction Specifications.....322

320.100 Construction322

320.108 Equipment Grounding Conductor.....322

Article 330—Metal-Clad Cable (Type MC)323

Part I. General323

330.1 Scope323

330.2 Definition.....323

330.6 Listing Requirements324

Part II. Installation324

330.10 Uses Permitted.....324

330.12 Uses Not Permitted.....325

330.15 Exposed Work.....325

330.17 Through or Parallel to Framing Members.....325

330.23 In Accessible Attics or Roof Spaces326

330.24 Bending Radius326

330.30 Securing and Supporting326

330.80 Conductor Ampacities328

Part III. Construction Specifications.....329

330.108 Equipment Grounding Conductor.....329

Article 334—Nonmetallic-Sheathed Cable (Type NM)331

Part I. General331

334.1 Scope331

334.2 Definition.....331

334.6 Listing Requirements331

Part II. Installation332

334.10 Uses Permitted.....332

334.12 Uses Not Permitted.....333

334.15 Exposed Work.....333

334.17 Through or Parallel to Framing Members.....334

334.23 Accessible Attics and Roof Spaces.....335

334.24 Bending Radius335

334.30 Securing and Supporting336

334.40 Boxes and Fittings.....337

334.80 Conductor Ampacity.....337

Part III. Construction Specifications.....338

334.108 Equipment Grounding Conductor.....338

| | |
|--|-----|
| Article 336—Power and Control Tray Cable (Type TC) | 339 |
| Part I. General | 339 |
| 336.1 Scope | 339 |
| 336.2 Definition | 339 |
| 336.6 Listing Requirements | 339 |
| Part II. Installation | 339 |
| 336.10 Uses Permitted | 339 |
| 336.12 Uses Not Permitted | 340 |
| 336.24 Bending Radius | 340 |
| | |
| Article 338—Service-Entrance Cable (Types SE and USE) | 341 |
| Part I. General | 341 |
| 338.1 Scope | 341 |
| 338.2 Definitions | 341 |
| 338.6 Listing Requirements | 342 |
| Part II. Installation | 342 |
| 338.10 Uses Permitted | 342 |
| 338.12 Uses Not Permitted | 343 |
| 338.24 Bending Radius | 343 |
| | |
| Article 340—Underground Feeder and Branch-Circuit Cable (Type UF) | 345 |
| Part I. General | 345 |
| 340.1 Scope | 345 |
| 340.2 Definition | 345 |
| 340.6 Listing Requirements | 345 |
| Part II. Installation | 345 |
| 340.10 Uses Permitted | 345 |
| 340.12 Uses Not Permitted | 346 |
| 340.24 Bends | 346 |
| 340.80 Ampacity | 346 |
| Part III. Construction Specifications | 346 |
| 340.108 Equipment Grounding Conductor | 346 |
| 340.112 Insulation | 346 |
| | |
| Article 342—Intermediate Metal Conduit (Type IMC) | 347 |
| Part I. General | 347 |
| 342.1 Scope | 347 |
| 342.2 Definition | 347 |
| 342.6 Listing Requirements | 347 |
| Part II. Installation | 348 |
| 342.10 Uses Permitted | 348 |
| 342.14 Dissimilar Metals | 348 |
| 342.20 Trade Size | 348 |
| 342.22 Number of Conductors | 348 |
| 342.24 Bends | 348 |
| 342.26 Number of Bends (360°) | 348 |
| 342.28 Reaming | 348 |
| 342.30 Securing and Supporting | 349 |
| 342.42 Couplings and Connectors | 350 |
| 342.46 Bushings | 350 |
| 342.60 Equipment Grounding Conductor | 351 |
| | |
| Article 344—Rigid Metal Conduit (Type RMC) | 353 |
| Part I. General | 353 |
| 344.1 Scope | 353 |
| 344.2 Definition | 353 |
| 344.6 Listing Requirements | 354 |
| Part II. Installation | 354 |
| 344.10 Uses Permitted | 354 |
| 344.14 Dissimilar Metals | 354 |
| 344.20 Trade Size | 354 |
| 344.22 Number of Conductors | 354 |
| 344.24 Bends | 355 |
| 344.26 Number of Bends (360°) | 355 |
| 344.28 Reaming | 355 |
| 344.30 Securing and Supporting | 355 |
| 344.42 Couplings and Connectors | 357 |
| 344.46 Bushings | 358 |
| 344.60 Equipment Grounding Conductor | 358 |
| | |
| Article 348—Flexible Metal Conduit (Type FMC) | 359 |
| Part I. General | 359 |
| 348.1 Scope | 359 |
| 348.2 Definition | 359 |
| 348.6 Listing Requirements | 359 |
| Part II. Installation | 359 |
| 348.10 Uses Permitted | 359 |
| 348.12 Uses Not Permitted | 359 |
| 348.20 Trade Size | 360 |
| 348.22 Number of Conductors | 360 |
| 348.24 Bends | 361 |
| 348.26 Number of Bends (360°) | 361 |
| 348.28 Trimming | 361 |
| 348.30 Securing and Supporting | 361 |
| 348.60 Equipment Grounding and Bonding Conductors | 362 |
| | |
| Article 350—Liquidtight Flexible Metal Conduit (Type LFMC) | 363 |
| Part I. General | 363 |
| 350.1 Scope | 363 |
| 350.2 Definition | 363 |
| 350.6 Listing Requirements | 363 |

Part II. Installation363

350.10 Uses Permitted.....363

350.12 Uses Not Permitted.....364

350.20 Trade Size364

350.22 Number of Conductors364

350.24 Bends365

350.26 Number of Bends (360°).....365

350.28 Trimming.....365

350.30 Securing and Supporting365

350.60 Equipment Grounding and Bonding Conductors.....366

Article 352—Rigid Polyvinyl Chloride Conduit (Type PVC).....369

Part I. General369

352.1 Scope369

352.2 Definition.....369

Part II. Installation369

352.10 Uses Permitted.....369

352.12 Uses Not Permitted.....370

352.20 Trade Size371

352.22 Number of Conductors371

352.24 Bends372

352.26 Number of Bends (360°).....372

352.28 Trimming.....372

352.30 Securing and Supporting372

352.44 Expansion Fittings.....373

352.46 Bushings373

352.48 Joints.....374

352.60 Equipment Grounding Conductor.....374

Article 356—Liquidtight Flexible Nonmetallic Conduit (Type LFNC).....377

Part I. General377

356.1 Scope377

356.2 Definition.....377

356.6 Listing Requirements377

Part II. Installation377

356.10 Uses Permitted.....377

356.12 Uses Not Permitted.....378

356.20 Trade Size378

356.22 Number of Conductors378

356.24 Bends379

356.26 Number of Bends (360°).....379

356.30 Securing and Supporting379

356.42 Fittings379

356.60 Equipment Grounding Conductor.....379

Article 358—Electrical Metallic Tubing (Type EMT).....381

Part I. General381

358.1 Scope381

358.2 Definition.....381

358.6 Listing Requirements381

Part II. Installation382

358.10 Uses Permitted.....382

358.12 Uses Not Permitted.....382

358.20 Trade Size382

358.22 Number of Conductors383

358.24 Bends383

358.26 Number of Bends (360°).....383

358.28 Reaming.....383

358.30 Securing and Supporting384

358.42 Couplings and Connectors.....385

358.60 Equipment Grounding Conductor.....385

Article 362—Electrical Nonmetallic Tubing (Type ENT).....387

Part I. General387

362.1 Scope387

362.2 Definition.....387

362.6 Listing.....387

Part II. Installation387

362.10 Uses Permitted.....387

362.12 Uses Not Permitted.....389

362.20 Trade Sizes.....389

362.22 Number of Conductors389

362.24 Bends390

362.26 Number of Bends (360°).....390

362.28 Trimming.....390

362.30 Securing and Supporting390

362.46 Bushings391

362.48 Joints.....391

362.60 Equipment Grounding Conductor.....391

Article 376—Metal Wireways.....393

Part I. General393

376.1 Scope393

376.2 Definition.....393

Part II. Installation393

376.10 Uses Permitted.....393

376.12 Uses Not Permitted.....394

376.20 Conductors Connected in Parallel.....394

376.22 Number of Conductors and Ampacity394

376.23 Wireway Sizing395

376.30 Supports396

376.56 Splices, Taps, and Power Distribution Blocks.....397

| | | | | |
|---|-----|---|-----------------------------------|-----|
| Part III. Construction Specifications | 398 | 400.10 | Uses Permitted..... | 414 |
| 376.100 Construction..... | 398 | 400.12 | Uses Not Permitted..... | 415 |
| Article 380—Multioutlet Assemblies | 399 | 400.14 | Pull at Joints and Terminals..... | 416 |
| Part I. General | 399 | 400.17 | Protection from Damage..... | 417 |
| 380.1 Scope..... | 399 | Article 404—Switches | | 419 |
| Part II. Installation | 399 | Part I. Installation | | 419 |
| 380.10 Uses Permitted..... | 399 | 404.1 Scope..... | | 419 |
| 380.12 Uses Not Permitted..... | 399 | 404.2 Switch Connections..... | | 419 |
| 380.76 Through Partitions..... | 399 | 404.3 Switch Enclosures..... | | 421 |
| Article 386—Surface Metal Raceways | 401 | 404.4 Damp or Wet Locations..... | | 422 |
| Part I. General | 401 | 404.7 Indicating..... | | 422 |
| 386.1 Scope..... | 401 | 404.8 Accessibility and Grouping..... | | 423 |
| 386.2 Definition..... | 401 | 404.9 General-Use Snap Switches, Dimmers, and Control Switches..... | | 425 |
| 386.6 Listing Requirements..... | 402 | 404.10 Mounting of Snap Switches, Dimmers, and Control Switches..... | | 426 |
| Part II. Installation | 402 | 404.12 Grounding of Enclosures..... | | 427 |
| 386.10 Uses Permitted..... | 402 | 404.14 Rating and Use of Snap Switches..... | | 427 |
| 386.12 Uses Not Permitted..... | 402 | Part II. Construction Specifications | | 427 |
| 386.21 Size of Conductors..... | 402 | 404.20 Switch Marking..... | | 427 |
| 386.22 Number of Conductors..... | 402 | 404.22 Electronic Control Switches..... | | 428 |
| 386.30 Securing and Supporting..... | 403 | Article 408—Switchboards and Panelboards | | 429 |
| 386.56 Splices and Taps..... | 403 | Part I. General | | 429 |
| 386.60 Equipment Grounding Conductor..... | 403 | 408.1 Scope..... | | 429 |
| 386.70 Separate Compartments..... | 403 | 408.3 Arrangement of Busbars and Conductors..... | | 429 |
| Article 392—Cable Trays | 405 | 408.4 Field Identification..... | | 430 |
| Part I. General | 405 | 408.5 Clearance for Conductors Entering Bus Enclosures..... | | 431 |
| 392.1 Scope..... | 405 | 408.6 Short-Circuit Current Rating..... | | 432 |
| 392.2 Definition..... | 405 | 408.7 Unused Openings..... | | 432 |
| Part II. Installation | 405 | 408.8 Reconditioning of Equipment..... | | 432 |
| 392.10 Uses Permitted..... | 405 | Part II. Switchboards and Switchgear | | 432 |
| 392.12 Uses Not Permitted..... | 407 | 408.18 Clearances..... | | 432 |
| 392.18 Cable Tray Installations..... | 407 | Part III. Panelboards | | 432 |
| 392.20 Cable and Conductor Installation..... | 408 | 408.36 Overcurrent Protection..... | | 432 |
| 392.30 Securing and Supporting..... | 408 | 408.37 Panelboards in Damp or Wet Locations..... | | 433 |
| 392.44 Expansion Splice Plates..... | 408 | 408.40 Equipment Grounding Conductor..... | | 433 |
| 392.46 Bushed Conduit and Tubing..... | 408 | 408.41 Neutral Conductor Terminations..... | | 434 |
| 392.56 Cable Splices..... | 408 | 408.43 Panelboard Orientation..... | | 434 |
| 392.60 Equipment Grounding Conductor..... | 409 | Article 445—Generators | | 435 |
| CHAPTER 4—EQUIPMENT FOR GENERAL USE | 411 | 445.1 Scope..... | | 435 |
| Article 400—Flexible Cords and Flexible Cables | 413 | 445.6 Listing..... | | 435 |
| 400.1 Scope..... | 413 | 445.11 Marking..... | | 435 |
| 400.3 Suitability..... | 413 | 445.13 Ampacity of Conductors..... | | 436 |
| 400.4 Types of Flexible Cords and Flexible Cables..... | 414 | 445.18 Disconnecting Means and Emergency Shutdown..... | | 436 |
| 400.5 Ampacity of Flexible Cords and Flexible Cables..... | 414 | | | |

Article 450—Transformers 439

450.1 Scope 439

450.3 Overcurrent Protection 439

450.9 Ventilation 440

450.10 Grounding and Bonding 440

450.13 Transformer Accessibility 440

450.14 Disconnecting Means 441

Article 480—Storage Batteries 443

480.1 Scope 443

480.2 Definitions 443

480.4 Battery and Cell Terminations 444

480.5 Wiring and Equipment Supplied from Batteries 445

480.7 Direct-Current Disconnect Methods 445

480.8 Insulation of Batteries 445

480.9 Battery Support Systems 445

480.10 Battery Locations 446

480.12 Battery Interconnections 446

480.13 Ground-Fault Detection 446

CHAPTER 6—SPECIAL EQUIPMENT 447

Article 690—Solar Photovoltaic (PV) Systems 449

Part I. General 449

690.1 Scope 449

690.2 Definitions 451

690.4 General Requirements 454

690.6 Alternating-Current Modules and Systems 455

Part II. Circuit Requirements 456

690.7 Maximum PV System Direct-Current Circuit Voltage 456

690.8 Circuit Current and Conductor Sizing 460

690.9 Overcurrent Protection 465

690.10 Stand-Alone Systems 467

690.11 Arc-Fault Circuit Protection 467

690.12 Rapid Shutdown 467

Part III. Disconnect 469

690.13 PV System Disconnect 469

690.15 PV Equipment Disconnecting Means to Isolate PV Equipment 470

Part IV. Wiring Methods 472

690.31 Wiring Methods 472

690.32 Component Interconnections 477

690.33 Connectors (Mating) 477

690.34 Access to Boxes 478

Part V. Grounding and Bonding 478

690.43 Equipment Grounding and Bonding 478

690.45 Size of Equipment Grounding Conductors 479

690.47 Grounding Electrode System 480

Part VI. Markings and Labels 481

690.53 Direct-Current PV Circuit Label 481

690.54 Interactive System Point of Interconnection 482

690.55 Energy Storage 482

690.56 Identification of Power Sources 482

Part VII. Connections to Other Sources 483

690.59 Connection to Other Power Sources 483

Part VIII. Energy Storage Systems 483

690.71 Energy Storage Systems 483

690.72 Self-Regulated PV Charge Control 484

Article 691—Large-Scale Photovoltaic (PV) Electric Supply Stations 485

691.1 Scope 485

691.2 Definitions 485

691.4 Special Requirements for Large-Scale PV Electric Supply Stations 485

691.5 Equipment 486

691.6 Engineered Design 486

691.7 Conformance of Construction to Engineered Design 486

691.8 Direct-Current Operating Voltage 486

691.9 Disconnect for Isolating Photovoltaic Equipment 486

691.10 Arc-Fault Mitigation 486

691.11 Fence Bonding and Grounding 486

CHAPTER 7—SPECIAL CONDITIONS 487

Article 705—Interconnected Electric Power Production Sources 489

Part I. General 489

705.1 Scope 489

705.2 Definitions 489

705.6 Equipment Approval 490

705.8 System Installation 490

705.10 Identification of Power Sources 490

705.11 Supply-Side Source Connections 491

705.12 Load-Side Source Connections 493

705.13 Power Control Systems 499

705.16 Interrupting and Short-Circuit Current Rating 500

705.20 Disconnect 500

705.25 Wiring Methods 500

705.28 Circuit Sizing and Current 500

705.30 Overcurrent Protection 501

705.32 Ground-Fault Protection 502

705.40 Loss of Utility Power 502

705.45 Unbalanced Interconnections 502

Part II. Microgrid Systems 504

705.50 System Operation 504

705.60 Primary Power Source Connection 504

| | | | |
|--|-----|--|-----|
| Article 706—Energy Storage Systems | 505 | Practice Questions | 517 |
| Part I. General | 505 | Final Exam A—Straight Order | 551 |
| 706.1 Scope..... | 505 | Final Exam B—Random Order | 563 |
| 706.2 Definitions..... | 506 | INDEX | 573 |
| 706.3 Qualified Personnel..... | 506 | About the Author | 583 |
| 706.4 System Requirements..... | 506 | About the Illustrator | 584 |
| 706.5 Listing..... | 507 | About the Mike Holt Team | 585 |
| 706.6 Multiple Systems..... | 507 | | |
| 706.8 Storage Batteries..... | 507 | | |
| 706.9 Maximum Voltage..... | 507 | | |
| Part II. Disconnect | 507 | | |
| 706.15 Disconnect..... | 507 | | |
| Part III. Installation Requirements | 508 | | |
| 706.20 General..... | 508 | | |
| 706.21 Directory (Identification of Power Sources)..... | 509 | | |
| Part IV. Circuit Requirements | 509 | | |
| 706.30 Circuit Sizing and Current..... | 509 | | |
| 706.31 Overcurrent Protection..... | 510 | | |
| 706.33 Charge Control..... | 510 | | |
| Part V. Flow Battery Energy Storage Systems | 511 | | |
| | | | |
| Article 710—Stand-Alone Systems | 513 | | |
| 710.1 Scope..... | 513 | | |
| 710.6 Equipment Approval..... | 513 | | |
| 710.10 Identification of Power Sources..... | 514 | | |
| 710.12 Stand-Alone Inverter Input Circuit Current..... | 514 | | |
| 710.15 General..... | 514 | | |