

Mike Holt's Understanding the NEC® Volume 1 Training Program



This document includes the Table of Contents from each book so you can see the full scope of this library.

Title	page #
Understanding the NEC, Volume 1, Art. 90—480	2
Understanding the NEC Workbook, Art. 90-480	12
Bonding and Grounding	14



Mike Holt's Illustrated Guide to
Understanding the National Electrical Code®
Volume 1

TABLE OF CONTENTS

About This Textbook	xv	110.25	Lockable Disconnecting Means	83
Additional Products to Help You Learn	xviii	Part II. 1,000V, Nominal, or Less	84
How to Use the <i>National Electrical Code</i>	1	110.26	Spaces About Electrical Equipment.....	84
		110.28	Enclosure Types	92
			Chapter 1—Practice Questions	95
Article 90—Introduction to the <i>National Electrical Code</i>	7			
90.1 Purpose of the <i>NEC</i>	7			
90.2 Scope of the <i>NEC</i>	8			
90.3 Code Arrangement.....	11			
90.4 Enforcement	12			
90.5 Mandatory Requirements and Explanatory Material	13			
90.7 Examination of Equipment for Product Safety	14			
Article 90—Practice Questions	15			
CHAPTER 1—GENERAL RULES	19			
Article 100—Definitions	21			
100 Definitions	21			
Article 110—Requirements for Electrical Installations	65			
Part I. General Requirements	65			
110.1 Scope	65			
110.2 Approval of Conductors and Equipment.....	65			
110.3 Use and Product Listing (Certification) of Equipment.....	66			
110.4 Voltage Rating of Electrical Equipment	66			
110.5 Conductor Material	66			
110.6 Conductor Sizes	67			
110.7 Wiring Integrity	67			
110.8 Suitable Wiring Methods	67			
110.9 Interrupting Rating (Overcurrent Protective Devices).....	68			
110.10 Equipment Short-Circuit Current Rating	68			
110.11 Deteriorating Agents.....	69			
110.12 Mechanical Execution of Work	70			
110.13 Mounting and Cooling of Equipment.....	72			
110.14 Conductor Termination and Splicing	72			
110.15 High-Leg Conductor Identification.....	79			
110.16 Arc Flash Hazard Warning.....	80			
110.21 Markings	81			
110.22 Identification of Disconnecting Means	82			
110.24 Available Fault Current	83			
CHAPTER 2—WIRING AND PROTECTION	101			
Article 200—Use and Identification of Grounded Conductors	103			
200.1 Scope	104			
200.2 General	104			
200.4 Neutral Conductor.....	104			
200.6 Identification of Grounded Conductors.....	105			
200.7 Use of White or Gray Color	107			
200.9 Means of Identification of Terminals.....	108			
200.10 Identification of Terminals.....	108			
Article 210—Branch Circuits	109			
Part I. General Provisions	109			
210.1 Scope	109			
210.3 Other Articles.....	110			
210.4 Multiwire Branch Circuits.....	110			
210.5 Identification for Branch Circuits	112			
210.7 Multiple Branch Circuits	114			
210.8 GFCI Protection.....	114			
210.11 Branch Circuits Required	121			
210.12 Arc-Fault Circuit-Interrupter Protection	123			
Part II. Branch-Circuit Ratings	124			
210.18 Branch-Circuit Rating.....	124			
210.19 Conductor Sizing	125			
210.20 Overcurrent Protection	128			
210.21 Receptacle Rating	129			
210.23 Permissible Loads, Multiple-Outlet Branch Circuits	130			
Part III. Required Outlets	130			
210.50 Receptacle Outlets	130			
210.52 Dwelling Unit Receptacle Outlet Requirements.....	131			
210.60 Receptacles in Guest Rooms, Guest Suites, Dormitory Units, and Similar Occupancies	138			
210.63 Equipment Requiring Servicing	139			

210.65	Meeting Rooms	140	225.19	Clearances from Buildings	178
210.70	Lighting Outlet Requirements.....	141	225.22	Raceways on Exterior Surfaces of Buildings or Other Structures	179
Article 215—Feeders.....		145	225.26	Trees for Conductor Support	179
215.1	Scope	145	225.27	Raceway Seals	180
215.2	Conductor Sizing	145	Part II. Buildings or Other Structures Supplied by a Feeder..... 180		
215.3	Overcurrent Protection Sizing.....	150	225.30	Number of Supplies	180
215.10	Ground-Fault Protection of Equipment	151	225.31	Disconnecting Means	181
215.12	Conductor Identification.....	151	225.32	Disconnecting Means Location	181
Article 220—Branch-Circuit, Feeder, and Service Load Calculations		153	225.33	Maximum Number of Disconnects	181
Part I. General		153	225.34	Grouping of Disconnects	182
220.1	Scope	153	225.37	Identification of Multiple Supplies.....	182
220.3	Application of Other Articles.....	153	225.39	Rating of Disconnecting Means.....	182
220.5	Calculations	154	Article 230—Services 183		
220.11	Floor Area	154	Part I. General		183
Part II. Branch-Circuit Load Calculations		155	230.1	Scope	183
220.12	Lighting Load for Non-Dwelling Occupancies	155	230.2	Number of Services	183
220.14	Other Loads—Occupancies	156	230.3	Not to Pass Through a Building	185
220.18	Motor-Operated Loads.....	160	230.6	Conductors Considered Outside a Building.....	185
Part III. Feeder and Service Calculations		160	230.7	Service Conductors Separate from Other Conductors	185
220.42	General Lighting Demand Factors	160	230.8	Raceway Seals	186
220.43	Show-Window and Track Lighting Loads, Commercial	161	230.9	Clearances on Buildings	186
220.44	Receptacle Load, Other Than Dwelling Units.....	162	230.10	Vegetation as Support.....	187
220.50	Motor Type Loads	162	Part II. Overhead Service Conductors		187
220.51	Fixed Electric Space-Heating Load	162	230.23	Overhead Service Conductor Size and Rating	187
220.52	Small-Appliance and Laundry Loads, Dwelling	162	230.24	Vertical Clearance for Overhead Service Conductors.....	188
220.53	Appliance Load, Dwelling.....	163	230.26	Point of Attachment	189
220.54	Clothes Dryer Demand Load, Dwelling	164	230.27	Means of Attachment	189
220.55	Cooking Appliances in Dwelling Units	165	230.28	Service Masts as Support	189
220.56	Kitchen Equipment Load, Commercial	167	Part III. Underground Service Conductors		190
220.60	Noncoincident Loads.....	168	230.30	Installation	190
220.61	Neutral Load	168	230.31	Underground Service Conductor Size and Rating	190
Part IV. Optional Calculations for Computing Feeder and Service Loads		170	230.32	Protection Against Damage	190
220.82	Optional Load Calculations, Dwellings.....	170	Part IV. Service-Entrance Conductors		191
220.84	Optional Load Calculations, Multifamily	171	230.40	Number of Service-Entrance Conductor Sets	191
220.85	Optional Load Calculations, Two Dwelling Units.....	172	230.42	Conductor Sizing	191
220.87	Determining Existing Loads	172	230.43	Wiring Methods	195
Article 225—Outside Branch Circuits and Feeders		175	230.46	Spliced Conductors	195
Part I. General		175	230.50	Protection Against Physical Damage	196
225.1	Scope	175	230.51	Cable Supports	197
225.6	Minimum Conductor Size and Support	175	230.53	Raceways to Drain	197
225.16	Attachment of Overhead Conductors	176	230.54	Overhead Service Locations	197
225.17	Masts as Supports	176	230.56	High-Leg Conductor Identification	198
225.18	Clearance for Overhead Conductors.....	177	Part V. Service Disconnect—General		199
			230.62	Service Equipment—Enclosed or Guarded	199
			230.66	Marking for Service Disconnect	199
			230.67	Surge Protection	199

Part VI. Service Disconnect—Disconnecting Means	200	Part II. Surge Protective Devices (SPDs), 1,000V or Less	232
230.70 Service Disconnect Requirements	200	242.6 Uses Not Permitted	232
230.71 Number of Service Disconnects	201	242.8 Listing	232
230.72 Grouping of Disconnects	202	242.10 Short-Circuit Current Rating	233
230.76 Manually or Power Operated	202	242.12 Type 1 SPDs—Line Side of Service Disconnect	233
230.79 Rating of Disconnect	202	242.14 Type 2 SPDs—Feeder Circuits	233
230.82 Connected on Supply Side of the Service Disconnect	203	242.20 Number Required	234
230.85 Emergency Disconnects	204	242.24 Routing of Surge Protection Device Conductors	234
Part VII. Service Disconnect Overcurrent Protection	204		
230.90 Overload Protection—Where Required	204		
230.91 Location	205		
230.95 Ground-Fault Protection of Equipment	206		
Article 240—Overcurrent Protection	207		
Part I. General	208		
240.1 Scope	208	250.1 Scope	235
240.2 Definitions	208	250.4 Performance Requirements for Grounding and Bonding	236
240.3 Other Articles (Overcurrent Protection of Equipment)	209	250.6 Objectionable Current	242
240.4 Overcurrent Protection of Conductors	209	250.8 Connection of Grounding and Bonding Connectors	246
240.5 Protection of Flexible Cords, Flexible Cables, and Fixture Wires	213	250.10 Protection of Ground Clamps and Fittings	246
240.6 Standard Ampere Ratings	213	250.12 Clean Surfaces	246
240.10 Supplementary Overcurrent Protection	214		
240.13 Ground-Fault Protection of Equipment	214	Part II. System Grounding and Bonding	247
240.15 Phase Conductor Overcurrent Device	215	250.20 Systems Required to be Grounded	247
Part II. Location	215	250.21 Ungrounded Systems	248
240.21 Location in Circuit	215	250.24 Grounding	248
240.24 Location of Overcurrent Protective Devices at Premises	221	250.25 Grounding for Supply Side of the Service Disconnect	252
Part III. Enclosures	223	250.28 Main Bonding Jumper and System Bonding Jumper	253
240.33 Vertical Position	223	250.30 Separately Derived Systems	254
Part IV. Disconnecting and Guarding	223	250.32 Buildings Supplied by a Feeder	263
240.40 Disconnecting Means for Fuses	223	250.34 Generators—Portable and Vehicle- or Trailer-Mounted	265
Part V. Plug Fuses, Fuseholders, and Adapters	224	250.36 High-Impedance Grounded Systems	266
240.51 Edison-Base Fuses	224		
Part VI. Cartridge Fuses and Fuseholders	224		
240.60 General	224	Part III. Grounding Electrode System and Grounding Electrode Conductor	267
240.67 Arc Energy Reduction—Fuses	225	250.50 Grounding Electrode System	267
Part VII. Circuit Breakers	226	250.52 Grounding Electrode Types	267
240.81 Indicating	226	250.53 Grounding Electrode Installation Requirements	270
240.83 Markings	226	250.54 Auxiliary Grounding Electrodes	275
240.85 Applications	227	250.58 Common Grounding Electrode	276
240.86 Series Ratings	228	250.62 Grounding Electrode Conductor	277
240.87 Arc Energy Reduction—Circuit Breakers	228	250.64 Grounding Electrode Conductor Installation	277
240.88 Reconditioned Equipment	229	250.66 Sizing Grounding Electrode Conductor	281
Article 242—Overvoltage Protection	231	250.68 Grounding Electrode Conductor and Bonding Jumper Connection to Grounding Electrodes	282
Part I. General	232	250.70 Grounding Electrode Conductor Termination Fittings	284
242.1 Scope	232	Part IV. Enclosure, Raceway, and Service Cable Connections	285
		250.80 Service Raceways and Enclosures	285
		250.86 Other Enclosures	285
		Part V. Bonding for Fault Current	285
		250.90 General	285
		250.92 Bonding Equipment Containing Service Conductors	285
		250.94 Bonding Communications Systems	288
		250.96 Bonding Other Enclosures	289
		250.97 Bonding Metal Parts Containing 277V and 480V Circuits	290

250.98	Bonding Loosely Jointed Metal Raceways.....	291
250.102	Neutral Conductor, Bonding Conductors, and Bonding Jumpers	291
250.104	Bonding of Piping Systems and Exposed Structural Metal.....	293
250.106	Lightning Protection Systems.....	297
Part VI. Equipment Grounding and Equipment Grounding Conductors. 298		
250.109	Metal Enclosures.....	298
250.114	Equipment Connected by Cord and Plug.....	298
250.118	Types of Equipment Grounding Conductors.....	299
250.119	Identification of Equipment Grounding Conductors.....	303
250.120	Equipment Grounding Conductor Installation.....	304
250.121	Restricted Use of Equipment Grounding Conductors	304
250.122	Sizing Equipment Grounding Conductors.....	304
Part VII. Methods of Equipment Grounding Conductor Connections 308		
250.134	Equipment Connected by Permanent Wiring Methods.....	308
250.136	Equipment Secured to Grounded Metal Supports	309
250.138	Cord-and-Plug-Connected	309
250.140	Frames of Ranges, Ovens, and Clothes Dryers.....	309
250.142	Neutral Conductor for Effective Ground-Fault Current Path.....	310
250.146	Connecting Receptacle Grounding Terminal to an Equipment Grounding Conductor	311
250.148	Continuity and Attachment of Equipment Grounding Conductors in Boxes.....	314
Chapter 2—Practice Questions 317		
CHAPTER 3—WIRING METHODS AND MATERIALS 323		
Article 300—General Requirements for Wiring Methods and Materials 327		
Part I. General Requirements 327		
300.1	Scope	327
300.3	Conductors	328
300.4	Protection Against Physical Damage	331
300.5	Underground Installations.....	334
300.6	Protection Against Corrosion and Deterioration	338
300.7	Raceways Exposed to Different Temperatures.....	339
300.9	Raceways in Wet Locations Above Grade	340
300.10	Electrical Continuity.....	340
300.11	Securing and Supporting	341
300.12	Mechanical Continuity	342
300.13	Mechanical and Electrical Continuity of Conductors—Splices and Pigtails	343
300.14	Length of Free Conductors	344
300.15	Boxes or Fittings	345
300.17	Number and Size of Conductors in a Raceway	347
300.18	Inserting Conductors in Raceways	349
300.19	Supporting Conductors in Vertical Raceways.....	350
300.20	Induced Alternating Currents in Ferrous Metal Parts	350
300.21	Spread of Fire or Products of Combustion	352
300.22	Wiring in Ducts and Plenum Spaces	353
300.23	Panels Designed to Allow Access	355
300.25	Exit Enclosures (Stair Towers).....	355
Article 310—Conductors for General Wiring 357		
Part I. General		
310.1	Scope	357
310.3	Conductors	357
Part II. Construction Specifications 358		
310.4	Conductor Construction and Application	358
310.6	Conductor Identification	361
Part III. Installation		
310.10	Uses Permitted	361
310.12	Single-Phase Dwelling Services and Feeders	364
310.14	Ampacities for Conductors Rated 0V to 2,000V	367
310.15	Ampacity Tables	368
310.16	Ampacities of Insulated Conductors in Raceways, Cables, or Buried	375
Article 312—Cabinets 377		
Part I. Scope and Installation		
312.1	Scope	377
312.2	Damp or Wet Locations	377
312.3	Position in Walls	378
312.4	Repairing Gaps in Noncombustible Surfaces	378
312.5	Enclosures	378
312.6	Deflection of Conductors	380
312.8	Overcurrent Device Enclosures	380
Part II. Construction Specifications 382		
312.10	Material	382
Article 314—Outlet, Pull, and Junction Boxes; Conduit Bodies; and Handhole Enclosures 383		
Part I. Scope and General		
314.1	Scope	383
314.3	Nonmetallic Boxes	383
314.4	Metal Boxes	384
Part II. Installation		
314.15	Damp or Wet Locations	384
314.16	Sizing Outlet Boxes	384
314.17	Conductors That Enter Boxes or Conduit Bodies	392
314.20	Flush-Mounted Box Installations	393
314.21	Repairing Noncombustible Surfaces	393
314.22	Surface Extensions	394
314.23	Support of Boxes	394

314.25	Covers and Canopies	397	Part II. Installation	420																																																																																																																																																																														
314.27	Outlet Box Requirements	398	334.10	Uses Permitted	420																																																																																																																																																																													
314.28	Sizing Pull and Junction Boxes.....	399	334.12	Uses Not Permitted.....	420																																																																																																																																																																													
314.29	Wiring to be Accessible.....	403	334.15	Exposed Work.....	421																																																																																																																																																																													
314.30	Handhole Enclosures.....	403	334.17	Through or Parallel to Framing Members.....	422																																																																																																																																																																													
Article 320—Armored Cable (Type AC)		405	334.23	Accessible Attics and Roof Spaces.....	423																																																																																																																																																																													
Part I. General		405	334.24	Bending Radius	423																																																																																																																																																																													
320.1	Scope	405	334.30	Securing and Supporting	424																																																																																																																																																																													
320.2	Definition.....	405	334.40	Boxes and Fittings.....	424																																																																																																																																																																													
320.6	Listing Requirements	406	334.80	Conductor Ampacity	425																																																																																																																																																																													
Part II. Installation		406	Part III. Construction Specifications	426																																																																																																																																																																														
320.10	Uses Permitted	406	334.108	Equipment Grounding Conductor	426																																																																																																																																																																													
320.12	Uses Not Permitted.....	406	Article 336—Power and Control Tray Cable (Type TC) 427																																																																																																																																																																															
320.15	Exposed Work.....	406	Part I. General		427	336.1	Scope	427	320.17	Through or Parallel to Framing Members.....	406	336.2	Definition.....	427	320.23	In Accessible Attics or Roof Spaces	407	336.6	Listing Requirements	427	320.24	Bending Radius	407	Part II. Installation	427	320.30	Securing and Supporting	408	336.10	Uses Permitted	427	320.40	Boxes and Fittings.....	409	336.12	Uses Not Permitted	428	320.80	Conductor Ampacity	409	336.24	Bending Radius	428	Part III. Construction Specifications		410	Article 338—Service-Entrance Cable (Types SE and USE) 429			320.100	Construction	410	Part I. General		429	338.1	Scope	429	320.108	Equipment Grounding Conductor	410	338.2	Definitions	429	Article 330—Metal-Clad Cable (Type MC) 411		411	338.6	Listing Requirements	430	Part I. General		411	Part II. Installation	430	330.1	Scope	411	338.10	Uses Permitted	430	330.2	Definition.....	411	338.12	Uses Not Permitted	431	330.6	Listing Requirements	412	338.24	Bending Radius	431	Part II. Installation		412	Article 340—Underground Feeder and Branch-Circuit Cable (Type UF) 433			330.10	Uses Permitted	412	Part I. General		433	340.1	Scope	433	330.12	Uses Not Permitted.....	413	340.2	Definition.....	433	330.15	Exposed Work.....	413	340.6	Listing Requirements	433	330.17	Through or Parallel to Framing Members.....	413	Part II. Installation	433	330.23	In Accessible Attics or Roof Spaces	413	340.10	Uses Permitted	433	330.24	Bending Radius	414	340.12	Uses Not Permitted	434	330.30	Securing and Supporting	414	340.24	Bends	434	330.80	Conductor Ampacities	416	340.80	Ampacity	434	Part III. Construction Specifications		417	Part III. Construction Specifications	434	330.108	Equipment Grounding Conductor	417	340.108	Equipment Grounding Conductor	434	Article 334—Nonmetallic-Sheathed Cable (Type NM) 419		419	340.112	Insulation	434	Part I. General		419	334.1	Scope	419	334.2	Definition.....	419	334.6	Listing Requirements	419
Part I. General		427	336.1	Scope	427																																																																																																																																																																													
320.17	Through or Parallel to Framing Members.....	406	336.2	Definition.....	427																																																																																																																																																																													
320.23	In Accessible Attics or Roof Spaces	407	336.6	Listing Requirements	427																																																																																																																																																																													
320.24	Bending Radius	407	Part II. Installation	427																																																																																																																																																																														
320.30	Securing and Supporting	408	336.10	Uses Permitted	427																																																																																																																																																																													
320.40	Boxes and Fittings.....	409	336.12	Uses Not Permitted	428																																																																																																																																																																													
320.80	Conductor Ampacity	409	336.24	Bending Radius	428																																																																																																																																																																													
Part III. Construction Specifications		410	Article 338—Service-Entrance Cable (Types SE and USE) 429																																																																																																																																																																															
320.100	Construction	410	Part I. General		429	338.1	Scope	429	320.108	Equipment Grounding Conductor	410	338.2	Definitions	429	Article 330—Metal-Clad Cable (Type MC) 411		411	338.6	Listing Requirements	430	Part I. General		411	Part II. Installation	430	330.1	Scope	411	338.10	Uses Permitted	430	330.2	Definition.....	411	338.12	Uses Not Permitted	431	330.6	Listing Requirements	412	338.24	Bending Radius	431	Part II. Installation		412	Article 340—Underground Feeder and Branch-Circuit Cable (Type UF) 433			330.10	Uses Permitted	412	Part I. General		433	340.1	Scope	433	330.12	Uses Not Permitted.....	413	340.2	Definition.....	433	330.15	Exposed Work.....	413	340.6	Listing Requirements	433	330.17	Through or Parallel to Framing Members.....	413	Part II. Installation	433	330.23	In Accessible Attics or Roof Spaces	413	340.10	Uses Permitted	433	330.24	Bending Radius	414	340.12	Uses Not Permitted	434	330.30	Securing and Supporting	414	340.24	Bends	434	330.80	Conductor Ampacities	416	340.80	Ampacity	434	Part III. Construction Specifications		417	Part III. Construction Specifications	434	330.108	Equipment Grounding Conductor	417	340.108	Equipment Grounding Conductor	434	Article 334—Nonmetallic-Sheathed Cable (Type NM) 419		419	340.112	Insulation	434	Part I. General		419	334.1	Scope	419	334.2	Definition.....	419	334.6	Listing Requirements	419																																																		
Part I. General		429	338.1	Scope	429																																																																																																																																																																													
320.108	Equipment Grounding Conductor	410	338.2	Definitions	429																																																																																																																																																																													
Article 330—Metal-Clad Cable (Type MC) 411		411	338.6	Listing Requirements	430																																																																																																																																																																													
Part I. General		411	Part II. Installation	430																																																																																																																																																																														
330.1	Scope	411	338.10	Uses Permitted	430																																																																																																																																																																													
330.2	Definition.....	411	338.12	Uses Not Permitted	431																																																																																																																																																																													
330.6	Listing Requirements	412	338.24	Bending Radius	431																																																																																																																																																																													
Part II. Installation		412	Article 340—Underground Feeder and Branch-Circuit Cable (Type UF) 433																																																																																																																																																																															
330.10	Uses Permitted	412	Part I. General		433	340.1	Scope	433	330.12	Uses Not Permitted.....	413	340.2	Definition.....	433	330.15	Exposed Work.....	413	340.6	Listing Requirements	433	330.17	Through or Parallel to Framing Members.....	413	Part II. Installation	433	330.23	In Accessible Attics or Roof Spaces	413	340.10	Uses Permitted	433	330.24	Bending Radius	414	340.12	Uses Not Permitted	434	330.30	Securing and Supporting	414	340.24	Bends	434	330.80	Conductor Ampacities	416	340.80	Ampacity	434	Part III. Construction Specifications		417	Part III. Construction Specifications	434	330.108	Equipment Grounding Conductor	417	340.108	Equipment Grounding Conductor	434	Article 334—Nonmetallic-Sheathed Cable (Type NM) 419		419	340.112	Insulation	434	Part I. General		419	334.1	Scope	419	334.2	Definition.....	419	334.6	Listing Requirements	419																																																																																																				
Part I. General		433	340.1	Scope	433																																																																																																																																																																													
330.12	Uses Not Permitted.....	413	340.2	Definition.....	433																																																																																																																																																																													
330.15	Exposed Work.....	413	340.6	Listing Requirements	433																																																																																																																																																																													
330.17	Through or Parallel to Framing Members.....	413	Part II. Installation	433																																																																																																																																																																														
330.23	In Accessible Attics or Roof Spaces	413	340.10	Uses Permitted	433																																																																																																																																																																													
330.24	Bending Radius	414	340.12	Uses Not Permitted	434																																																																																																																																																																													
330.30	Securing and Supporting	414	340.24	Bends	434																																																																																																																																																																													
330.80	Conductor Ampacities	416	340.80	Ampacity	434																																																																																																																																																																													
Part III. Construction Specifications		417	Part III. Construction Specifications	434																																																																																																																																																																														
330.108	Equipment Grounding Conductor	417	340.108	Equipment Grounding Conductor	434																																																																																																																																																																													
Article 334—Nonmetallic-Sheathed Cable (Type NM) 419		419	340.112	Insulation	434																																																																																																																																																																													
Part I. General		419																																																																																																																																																																																
334.1	Scope	419																																																																																																																																																																																
334.2	Definition.....	419																																																																																																																																																																																
334.6	Listing Requirements	419																																																																																																																																																																																

Article 342—Intermediate Metal Conduit (Type IMC)	435	348.28	Trimming	449
Part I. General	435	348.30	Securing and Supporting	449
342.1 Scope	435	348.60	Equipment Grounding and Bonding Conductors.....	450
342.2 Definition.....	435			
342.6 Listing Requirements	436			
Part II. Installation	436			
342.10 Uses Permitted.....	436			
342.14 Dissimilar Metals.....	436			
342.20 Trade Size	436			
342.22 Number of Conductors	436			
342.24 Bends	436			
342.26 Number of Bends (360°).....	436			
342.28 Reaming.....	436			
342.30 Securing and Supporting	437			
342.42 Couplings and Connectors.....	438			
342.46 Bushings	438			
342.60 Equipment Grounding Conductor.....	439			
Article 344—Rigid Metal Conduit (Type RMC)	441			
Part I. General	441			
344.1 Scope	441			
344.2 Definition.....	441			
344.6 Listing Requirements	442			
Part II. Installation	442			
344.10 Uses Permitted.....	442			
344.14 Dissimilar Metals.....	442			
344.20 Trade Size	442			
344.22 Number of Conductors	442			
344.24 Bends	443			
344.26 Number of Bends (360°).....	443			
344.28 Reaming.....	443			
344.30 Securing and Supporting	443			
344.42 Couplings and Connectors.....	445			
344.46 Bushings	446			
344.60 Equipment Grounding Conductor.....	446			
Article 348—Flexible Metal Conduit (Type FMC)	447			
Part I. General	447			
348.1 Scope	447			
348.2 Definition.....	447			
348.6 Listing Requirements	447			
Part II. Installation	447			
348.10 Uses Permitted.....	447			
348.12 Uses Not Permitted.....	447			
348.20 Trade Size	448			
348.22 Number of Conductors	448			
348.24 Bends	449			
348.26 Number of Bends (360°).....	449			
Article 350—Liquidtight Flexible Metal Conduit (Type LFMC)	451			
Part I. General	451			
350.1 Scope	451			
350.2 Definition.....	451			
350.6 Listing Requirements	451			
Part II. Installation	452			
350.10 Uses Permitted.....	452			
350.12 Uses Not Permitted.....	452			
350.20 Trade Size	452			
350.22 Number of Conductors	452			
350.24 Bends	453			
350.26 Number of Bends (360°).....	453			
350.28 Trimming	453			
350.30 Securing and Supporting	453			
350.60 Equipment Grounding and Bonding Conductors.....	454			
Article 352—Rigid Polyvinyl Chloride Conduit (Type PVC)	457			
Part I. General	457			
352.1 Scope	457			
352.2 Definition.....	457			
Part II. Installation	457			
352.10 Uses Permitted.....	457			
352.12 Uses Not Permitted.....	458			
352.20 Trade Size	459			
352.22 Number of Conductors	459			
352.24 Bends	460			
352.26 Number of Bends (360°).....	460			
352.28 Trimming	460			
352.30 Securing and Supporting	460			
352.44 Expansion Fittings.....	461			
352.46 Bushings	462			
352.48 Joints	462			
352.60 Equipment Grounding Conductor.....	462			
Article 356—Liquidtight Flexible Nonmetallic Conduit (Type LFNC)	465			
Part I. General	465			
356.1 Scope	465			
356.2 Definition.....	465			
356.6 Listing Requirements	465			
Part II. Installation	465			
356.10 Uses Permitted.....	465			
356.12 Uses Not Permitted.....	466			

356.20	Trade Size	466	376.12	Uses Not Permitted.....	482
356.22	Number of Conductors.....	466	376.20	Conductors Connected in Parallel.....	482
356.24	Bends	467	376.22	Number of Conductors and Ampacity	482
356.26	Number of Bends (360°).....	467	376.23	Wireway Sizing	484
356.30	Securing and Supporting	467	376.30	Supports	485
356.42	Fittings	467	376.56	Splices, Taps, and Power Distribution Blocks.....	485
356.60	Equipment Grounding Conductor.....	468	Part III. Construction Specifications.....		
			376.100	Construction	486
Article 358—Electrical Metallic Tubing (Type EMT).....			469		
Part I. General			469		
358.1	Scope	469	380.1	Scope	487
358.2	Definition.....	469	Part II. Installation		
358.6	Listing Requirements	470	380.10	Uses Permitted.....	487
Part II. Installation			380.12	Uses Not Permitted.....	487
358.10	Uses Permitted.....	470	380.76	Through Partitions	487
358.12	Uses Not Permitted.....	470	Article 380—Multioutlet Assemblies.....		
358.20	Trade Size	471	Part I. General		
358.22	Number of Conductors.....	471	386.1	Scope	489
358.24	Bends	471	386.2	Definition.....	489
358.26	Number of Bends (360°).....	471	386.6	Listing Requirements	490
358.28	Reaming.....	471	Part II. Installation		
358.30	Securing and Supporting	472	386.10	Uses Permitted.....	490
358.42	Couplings and Connectors.....	473	386.12	Uses Not Permitted.....	490
358.60	Equipment Grounding Conductor.....	473	386.21	Size of Conductors.....	490
Article 362—Electrical Nonmetallic Tubing (Type ENT).....			386.22	Number of Conductors	490
Part I. General			386.30	Securing and Supporting	491
362.1	Scope	475	386.56	Splices and Taps	491
362.2	Definition.....	475	386.60	Equipment Grounding Conductor.....	491
362.6	Listing.....	475	386.70	Separate Compartments.....	491
Part II. Installation			Article 392—Cable Trays.....		
362.10	Uses Permitted.....	475	Part I. General		
362.12	Uses Not Permitted.....	477	392.1	Scope	493
362.20	Trade Sizes.....	477	392.2	Definition.....	493
362.22	Number of Conductors	477	Part II. Installation		
362.24	Bends	478	392.10	Uses Permitted.....	493
362.26	Number of Bends (360°).....	478	392.12	Uses Not Permitted.....	495
362.28	Trimming	478	392.18	Cable Tray Installations	495
362.30	Securing and Supporting	478	392.20	Cable and Conductor Installation	496
362.46	Bushings	479	392.30	Securing and Supporting	496
362.48	Joints	479	392.44	Expansion Splice Plates	496
362.60	Equipment Grounding Conductor.....	479	392.46	Bushed Conduit and Tubing	496
Article 376—Metal Wireways.....			392.56	Cable Splices	496
Part I. General			392.60	Equipment Grounding Conductor.....	497
376.1	Scope	481	Chapter 3—Practice Questions.....		
376.2	Definition.....	481	499		
Part II. Installation					
376.10	Uses Permitted.....	482			

CHAPTER 4—EQUIPMENT FOR GENERAL USE	505	406.7	Attachment Plugs and Flanged Surface Devices	534
Article 400—Flexible Cords and Flexible Cables	507	406.9	Receptacles in Damp or Wet Locations.....	534
400.1 Scope	507	406.11	Connecting Receptacle Grounding Terminal to Equipment	
400.3 Suitability	507		Grounding Conductor	537
400.4 Types of Flexible Cords and Flexible Cables.....	508	406.12	Tamper-Resistant Receptacles.....	537
400.5 Ampacity of Flexible Cords and Flexible Cables	508			
400.10 Uses Permitted.....	508			
400.12 Uses Not Permitted.....	509			
400.14 Pull at Joints and Terminals	510			
400.17 Protection from Damage	510			
Article 402—Fixture Wires	513			
402.1 Scope	513			
402.2 Other Articles.....	513			
402.3 Types	513			
402.5 Ampacity of Fixture Wires.....	513			
402.6 Minimum Size	513			
402.7 Raceway Size.....	514			
402.8 Neutral Conductor.....	514			
402.10 Uses Permitted.....	514			
402.12 Uses Not Permitted.....	515			
Article 404—Switches	517			
Part I. Installation	517			
404.1 Scope	517			
404.2 Switch Connections	517			
404.3 Switch Enclosures.....	519			
404.4 Damp or Wet Locations	519			
404.7 Indicating	520			
404.8 Accessibility and Grouping	521			
404.9 General-Use Snap Switches, Dimmers, and Control Switches	523			
404.10 Mounting of Snap Switches, Dimmers, and Control Switches	524			
404.12 Grounding of Enclosures	525			
404.14 Rating and Use of Snap Switches	525			
Part II. Construction Specifications	525			
404.20 Switch Marking	525			
404.22 Electronic Control Switches.....	526			
Article 406—Receptacles, Attachment Plugs, and Cord Connectors	527			
406.1 Scope	527			
406.2 Definitions.....	527			
406.3 Receptacle Rating and Type	527			
406.4 General Installation Requirements.....	528			
406.5 Receptacle Mounting.....	531			
406.6 Receptacle Faceplates	533			
Article 408—Switchboards and Panelboards	539			
Part I. General	539			
408.1 Scope	539			
408.3 Arrangement of Busbars and Conductors.....	539			
408.4 Field Identification.....	540			
408.5 Clearance for Conductors Entering Bus Enclosures	541			
408.6 Short-Circuit Current Rating.....	542			
408.7 Unused Openings	542			
408.8 Reconditioning of Equipment	542			
Part II. Switchboards and Switchgear	542			
408.18 Clearances	542			
Part III. Panelboards	543			
408.36 Overcurrent Protection	543			
408.37 Panelboards in Damp or Wet Locations	543			
408.40 Equipment Grounding Conductor.....	543			
408.41 Neutral Conductor Terminations	544			
408.43 Panelboard Orientation.....	544			
Article 410—Luminaires, Lampholders, and Lamps	545			
Part I. General	545			
410.1 Scope	545			
410.2 Definitions	546			
410.6 Listing Required	546			
410.7 Reconditioned Equipment.....	546			
Part II. Luminaire Locations	546			
410.10 Luminaires in Specific Locations	546			
410.16 Luminaires in Clothes Closets	548			
Part III. Luminaire Outlet Boxes and Covers	549			
410.22 Outlet Boxes to be Covered.....	549			
410.24 Connection of Electric-Discharge and LED Luminaires	549			
Part IV. Luminaire Supports	550			
410.30 Supports	550			
410.36 Means of Support	551			
Part V. Grounding (Bonding)	552			
410.44 Equipment Grounding Conductor.....	552			
410.46 Equipment Grounding Conductor Attachment	552			
Part VI. Wiring of Luminaires	552			
410.62 Cord-Connected Luminaires	552			
Part X. Special Provisions for Flush and Recessed Luminaires	553			
410.115 Temperature	553			
410.116 Clearance and Installation.....	553			
410.118 Access to Other Boxes.....	554			

Part XII. Electric-Discharge Lighting	554	424.4 Branch Circuits	567
410.130 General	554	Part III. Electric Space-Heating Equipment	568
Part XIV. Track Lighting	554	424.19 Disconnecting Means	568
410.151 Installation	554	Part V. Electric Space-Heating Cables	569
410.154 Fastening	555	424.44 Electric Heating Cables in Concrete or Masonry Floors	569
Part XVI. Special Provisions for Horticultural Lighting Equipment	555	Part VI. Duct Heaters	569
410.170 General	555	424.65 Location of Disconnecting Means for Electric Duct Heater Controllers	569
410.172 Listing	555		
410.174 Installation and Use	555		
410.176 Locations Not Permitted	555		
410.178 Flexible Cord	555		
410.180 Fittings and Connectors	555		
410.182 Grounding	556		
410.184 Ground-Fault Circuit-Interrupter Protection	556		
410.186 Support	556		
Article 411—Low-Voltage Lighting	557		
411.1 Scope	557		
411.3 Low-Voltage Lighting Systems	557		
411.4 Listing Required	557		
411.5 Specific Location Requirements	558		
Article 422—Appliances	559		
Part I. General	559		
422.1 Scope	559		
422.3 Other Articles	559		
422.5 GFCI Protection	559		
422.6 Listing Required	561		
Part II. Branch-Circuit Requirements	561		
422.10 Branch Circuits	561		
422.11 Overcurrent Protection	561		
422.12 Central Heating Equipment	561		
422.13 Storage Water Heaters	561		
422.15 Central Vacuums	562		
422.16 Flexible Cords	563		
422.18 Support of Ceiling-Suspended (Paddle) Fans	565		
422.19 Space for Conductors	565		
422.20 Outlet Boxes to be Covered	565		
Part III. Disconnecting Means	565		
422.30 Disconnection—General	565		
422.31 Permanently Connected Appliance Disconnects	565		
422.33 Disconnection of Cord-and-Plug-Connected or Attachment Fitting-Connected Appliances	566		
Article 424—Fixed Electric Space-Heating Equipment	567		
Part I. General	567		
424.1 Scope	567		
424.3 Other Articles	567		
424.4 Branch Circuits	567		
Part III. Electric Space-Heating Equipment	568		
424.19 Disconnecting Means	568		
Part V. Electric Space-Heating Cables	569		
424.44 Electric Heating Cables in Concrete or Masonry Floors	569		
Part VI. Duct Heaters	569		
424.65 Location of Disconnecting Means for Electric Duct Heater Controllers	569		
Article 430—Motors, Motor Circuits, and Controllers	571		
Part I. General	571		
430.1 Scope	571		
430.2 Definitions	572		
430.6 Table FLC versus Motor Nameplate Current Rating	572		
430.14 Location of Motors	573		
430.17 Highest Rated Motor	573		
Part II. Conductor Size	574		
430.22 Single Motor Conductor Size	574		
430.24 Several Motors—Conductor Size	576		
Part III. Motor and Branch-Circuit Overload Protection	576		
430.31 Overload	576		
430.32 Overload Sizing for Continuous-Duty Motors	577		
Part IV. Branch-Circuit Short-Circuit and Ground-Fault Protection	579		
430.51 General	579		
430.52 Branch-Circuit Short-Circuit and Ground-Fault Protection	580		
430.55 Combined Overcurrent Protective Device	581		
Part V. Feeder Short-Circuit and Ground-Fault Protection	582		
430.62 Motor Feeder Protection	582		
Part VI. Motor Control Circuits	584		
430.72 Overcurrent Protection for Control Circuits	584		
430.75 Disconnect for Control Circuits	584		
Part VII. Motor Controllers	584		
430.83 Motor Controller Horsepower Rating	584		
Part IX. Disconnecting Means	585		
430.102 Disconnect Location	585		
430.107 Readily Accessible	586		
430.109 Type of Disconnecting Means	586		
Part X. Adjustable-Speed Drive Systems	586		
430.120 General	586		
430.122 Conductor Sizing	586		
430.124 Overload Protection	588		
430.128 Disconnecting Means	588		
430.130 Branch-Circuit Short-Circuit and Ground-Fault Protection	588		
Part XIV. Tables	588		

Article 440—Air-Conditioning and Refrigeration Equipment	591	Article 480—Storage Batteries	607
Part I. General	591	480.1 Scope	607
440.1 Scope	591	480.2 Definitions	607
440.2 Definitions	591	480.4 Battery and Cell Terminations	608
440.3 Other Articles	591	480.5 Wiring and Equipment Supplied from Batteries	609
440.4 Marking on Hermetic Refrigerant Motor-Compressors and Equipment	592	480.7 Direct-Current Disconnect Methods	609
440.9 Grounding and Bonding	593	480.8 Insulation of Batteries	609
Part II. Disconnecting Means	593	480.9 Battery Support Systems	609
440.14 Location	593	480.10 Battery Locations	610
Part III. Overcurrent Protection	594	480.12 Battery Interconnections	610
440.21 General	594	480.13 Ground-Fault Detection	610
440.22 Short-Circuit and Ground-Fault Overcurrent Device Size	594	Chapter 4—Practice Questions	611
Part IV. Conductor Sizing	595	Final Exam A—Straight Order	617
440.33 Motor-Compressor(s) With or Without Additional Motor Loads	595	Final Exam B—Random Order	627
 Article 445—Generators	599	 INDEX	637
445.1 Scope	599	 About the Author	645
445.6 Listing	599	 About the Illustrator	646
445.11 Marking	599	 About the Mike Holt Team	647
445.13 Ampacity of Conductors	600		
445.18 Disconnecting Means and Emergency Shutdown	600		
 Article 450—Transformers	603		
450.1 Scope	603		
450.3 Overcurrent Protection	603		
450.9 Ventilation	604		
450.10 Grounding and Bonding	604		
450.13 Transformer Accessibility	605		
450.14 Disconnecting Means	605		

Mike Holt's Illustrated Guide to
**Understanding the National Electrical
Code® Workbook (Articles 90-480)**

TABLE OF CONTENTS

About This Workbook	vii
Additional Products to Help You Learn	viii
How to Use the <i>National Electrical Code</i>	1
Article 90—Introduction to the <i>National Electrical Code</i>	7
CHAPTER 1—GENERAL RULES 11	
Article 100—Definitions	13
Article 110—Requirements for Electrical Installations	29
CHAPTER 2—WIRING AND PROTECTION 39	
Article 200—Use and Identification of Grounded Conductors	41
Article 210—Branch Circuits	45
Article 215—Feeders	57
Article 220—Branch-Circuit, Feeder, and Service Load Calculations	59
Article 225—Outside Branch Circuits and Feeders	65
Article 230—Services	69
Article 240—Overcurrent Protection	77
Article 242—Overvoltage Protection	83
Article 250—Grounding and Bonding	87
CHAPTER 3—WIRING METHODS AND MATERIALS 109	
Article 300—General Requirements for Wiring Methods and Materials	113
Article 310—Conductors for General Wiring	123
Article 312—Cabinets	127
Article 314—Outlet, Pull, and Junction Boxes; Conduit Bodies; and Handhole Enclosures	129
Article 320—Armored Cable (Type AC)	137
Article 330—Metal-Clad Cable (Type MC)	139
Article 334—Nonmetallic-Sheathed Cable (Type NM)	141
Article 336—Power and Control Tray Cable (Type TC)	145
Article 338—Service-Entrance Cable (Types SE and USE)	147
Article 340—Underground Feeder and Branch-Circuit Cable (Type UF)	149
Article 342—Intermediate Metal Conduit (Type IMC)	151
Article 344—Rigid Metal Conduit (Type RMC)	153
Article 348—Flexible Metal Conduit (Type FMC)	155
Article 350—Liquidtight Flexible Metal Conduit (Type LFMC)	157
Article 352—Rigid Polyvinyl Chloride Conduit (Type PVC)	159
Article 356—Liquidtight Flexible Nonmetallic Conduit (Type LFNC)	161
Article 358—Electrical Metallic Tubing (Type EMT)	163

Article 362—Electrical Nonmetallic Tubing (Type ENT).....	165	Article 424—Fixed Electric Space-Heating Equipment	207
Article 376—Metal Wireways.....	167	Article 430—Motors, Motor Circuits, and Controllers.....	209
Article 380—Multioutlet Assemblies.....	169	Article 440—Air-Conditioning and Refrigeration Equipment	213
Article 386—Surface Metal Raceways.....	171	Article 445—Generators.....	215
Article 392—Cable Trays.....	173	Article 450—Transformers.....	217
CHAPTER 4—EQUIPMENT FOR GENERAL USE 175			
Article 400—Flexible Cords and Flexible Cables.....	177	Article 480—Storage Batteries.....	219
Article 402—Fixture Wires.....	179	Final Exam A—Straight Order..... 223	
Article 404—Switches.....	181	Final Exam B—Random Order..... 233	
Article 406—Receptacles, Attachment Plugs, and Cord Connectors.....	185	About the Author	243
Article 408—Switchboards and Panelboards	191	About the Illustrator	244
Article 410—Luminaires, Lampholders, and Lamps.....	195	About the Mike Holt Team	245
Article 411—Low-Voltage Lighting	201		
Article 422—Appliances.....	203		



Mike Holt's Illustrated Guide to
**Understanding NEC® Requirements for
Bonding and Grounding**

TABLE OF CONTENTS

About This Textbook	x	Part B Ground-Fault Circuit Interrupters (GFCIs)	41
Additional Products to Help You Learn	xiii	4.6 Ground-Fault Circuit Interrupters (GFCIs)	41
How to Use the <i>National Electrical Code</i>	1	4.7 Neutral-to-Case Detection	41
SECTION I—ELECTRICAL FUNDAMENTALS	7	4.8 Line-to-Neutral Shock Hazard	42
Unit 1—Matter	9	4.9 GFCI Fails—Circuit Remains Energized	42
1.1 Atomic Theory	9	4.10 GFCI Test Button	43
1.2 Electrostatic Force	11		
1.3 Atomic Charges	11	Unit 4—Practice Questions	45
1.4 Charged Material (Static Charge)	12		
1.5 High-Voltage Electrostatic Discharge	13		
1.6 Lightning	14		
1.7 Lightning Protection	15		
Unit 1—Practice Questions	17		
Unit 2—Electron Theory	21		
2.1 Electron Orbitals	21		
2.2 Valence Electrons	21		
2.3 Freeing Electrons from an Atom	22		
2.4 Conductance	22		
Unit 2—Practice Questions	25		
Unit 3—Sources, Uses, and Dangers of Electricity	27		
3.1 Electrical Power Source	27		
3.2 Electric Current Flow (Electricity)	27		
3.3 Electricity	28		
3.4 Dangers of Electricity	29		
3.5 <i>National Electrical Code</i>	31		
Unit 3—Practice Questions	33		
Unit 4—Circuit Protective Devices	37		
Part A Overcurrent Protection Devices	37		
4.1 Overcurrent Protection	37		
4.2 Clearing Faults	38		
4.3 Overcurrent Protective Device Types	39		
4.4 Fuses	39		
4.5 Circuit Breaker Trip Elements	40		
		CHAPTER 1—GENERAL RULES	61
		Article 100—Definitions	63
		100 Definitions	63
		Article 110—Requirements for Electrical Installations	85
		110.1 Scope	85
		110.2 Approval of Conductors and Equipment	85
		110.3 Examination, Identification, Installation, Use, and Product Listing (Certification) of Equipment	86
		110.5 Conductor Material	86
		110.6 Conductor Sizes	86
		110.7 Wiring Integrity	86
		110.8 Suitable Wiring Methods	87
		110.11 Deteriorating Agents	87
		110.14 Conductor Termination and Splicing	88
		Chapter 1—Practice Questions	93

CHAPTER 2—WIRING AND PROTECTION	99	250.98	Bonding Loosely Jointed Metal Raceways.....	155
Article 250—Grounding and Bonding	101	250.102	Neutral Conductor, Bonding Conductors, and Bonding Jumpers.....	156
Part I. General	101	250.104	Bonding of Piping Systems and Exposed Structural Metal....	158
250.1 Scope	101	250.106	Lightning Protection Systems.....	162
250.4 Performance Requirements for Grounding and Bonding	102	Part VI. Equipment Grounding and Equipment Grounding Conductors	162	
Earth Shells	106	250.109	Metal Enclosures.....	162
250.6 Objectionable Current.....	108	250.114	Equipment Connected by Cord and Plug.....	162
Objectionable Current	109	250.118	Types of Equipment Grounding Conductors.....	163
Dangers of Objectionable Current	110	250.119	Identification of Equipment Grounding Conductors	167
250.8 Connection of Grounding and Bonding Connectors.....	112	250.120	Equipment Grounding Conductor Installation.....	168
250.10 Protection of Ground Clamps and Fittings	112	250.121	Restricted Use of Equipment Grounding Conductors	168
250.12 Clean Surfaces	112	250.122	Sizing Equipment Grounding Conductors.....	169
Part II. System Grounding and Bonding	113	Part VII. Methods of Equipment Grounding Conductor Connections	172	
250.20 Systems Required to be Grounded	113	250.134	Equipment Connected by Permanent Wiring Methods.....	172
250.21 Ungrounded Systems	113	250.136	Equipment Secured to Grounded Metal Supports	173
250.24 Grounding	114	250.138	Cord-and-Plug-Connected	173
250.25 Grounding for Supply Side of the Service Disconnect	118	250.140	Frames of Ranges, Ovens, and Clothes Dryers.....	174
250.28 Main Bonding Jumper and System Bonding Jumper.....	119	250.142	Neutral Conductor for Effective Ground-Fault Current Path.....	174
250.30 Separately Derived Systems.....	120	250.146	Connecting Receptacle Grounding Terminal to an Equipment Grounding Conductor.....	175
Special Section 250.30 Separately Derived Systems	126	250.148	Continuity and Attachment of Equipment Grounding Conductors in Boxes.....	178
250.32 Buildings Supplied by a Feeder	129	Chapter 2—Practice Questions	181	
250.34 Generators—Portable and Vehicle- or Trailer-Mounted	131			
250.36 High-Impedance Grounded Systems.....	131			
Part III. Grounding Electrode System and Grounding Electrode Conductor	132			
250.50 Grounding Electrode System	132			
250.52 Grounding Electrode Types.....	133			
250.53 Grounding Electrode Installation Requirements.....	135			
Measuring the Contact Resistance of Electrodes to Earth	139			
Soil Resistivity	140			
250.54 Auxiliary Grounding Electrodes	140	CHAPTER 3—WIRING METHODS AND MATERIALS	193	
250.58 Common Grounding Electrode	142			
250.62 Grounding Electrode Conductor	142	Article 300—General Requirements for Wiring Methods and Materials	197	
250.64 Grounding Electrode Conductor Installation	142	300.1 Scope	197	
250.66 Sizing Grounding Electrode Conductor.....	146	300.3 Conductors	198	
250.68 Grounding Electrode Conductor and Bonding Jumper Connection to Grounding Electrodes	147	300.10 Electrical Continuity.....	199	
250.70 Grounding Electrode Conductor Termination Fittings.....	149	300.20 Induced Alternating Currents in Ferrous Metal Parts	200	
Part IV. Enclosure, Raceway, and Service Cable Connections	150			
250.80 Service Raceways and Enclosures	150	Article 314—Outlet, Device, Pull, and Junction Boxes; Conduit Bodies; and Handhole Enclosures	203	
250.86 Other Enclosures.....	150	314.1 Scope	203	
Part V. Bonding for Fault Current	150	314.3 Nonmetallic Boxes	203	
250.90 General.....	150	314.4 Metal Boxes	203	
250.92 Bonding Equipment Containing Service Conductors	150	Part II. Installation	204	
250.94 Bonding Communications Systems	152	314.25 Covers and Canopies	204	
250.96 Bonding Other Enclosures.....	154	314.28 Sizing Pull and Junction Boxes.....	204	
250.97 Bonding Metal Parts Containing 277V and 480V Circuits	154	314.30 Handhole Enclosures.....	205	

Article 320—Armored Cable (Type AC).....	207	Article 386—Surface Metal Raceways.....	225
320.1 Scope	207	386.1 Scope	225
320.2 Definition.....	207	386.2 Definition.....	225
320.108 Equipment Grounding Conductor.....	207	386.60 Equipment Grounding Conductor.....	226
Article 330—Metal-Clad Cable (Type MC).....	209	Article 392—Cable Trays.....	227
330.1 Scope	209	392.1 Scope	227
330.2 Definition.....	209	392.2 Definition.....	227
330.108 Equipment Grounding Conductor.....	210	392.60 Equipment Grounding Conductor.....	227
Article 334—Nonmetallic-Sheathed Cable (Type NM).....	211	Chapter 3—Practice Questions.....	229
334.1 Scope	211		
334.2 Definition.....	211		
334.108 Equipment Grounding Conductor.....	211		
Article 348—Flexible Metal Conduit (Type FMC).....	213	CHAPTER 4—EQUIPMENT FOR GENERAL USE.....	231
348.1 Scope	213	Article 404—Switches.....	233
348.2 Definition.....	213	404.1 Scope	233
348.60 Equipment Grounding and Bonding Conductors	213	404.9 General-Use Snap Switches, Dimmers, and Control Switches	233
404.12 Grounding of Enclosures	234		
Article 350—Liquidtight Flexible Metal Conduit (Type LFMC).....	215	Article 406—Receptacles and Attachment Plugs (Caps).....	235
350.1 Scope	215	406.1 Scope	235
350.2 Definition.....	215	406.3 Receptacle Rating and Type	235
350.60 Equipment Grounding and Bonding Conductors	215	406.4 General Installation Requirements.....	235
406.6 Receptacle Faceplates	238	406.6 Receptacle Faceplates	238
406.11 Connecting Receptacle Grounding Terminal to Equipment Grounding Conductor	238	406.11 Connecting Receptacle Grounding Terminal to Equipment Grounding Conductor	238
Article 352—Rigid Polyvinyl Chloride Conduit (Type PVC).....	217	Article 408—Switchboards and Panelboards.....	239
352.1 Scope	217	408.1 Scope	239
352.2 Definition.....	217	408.40 Equipment Grounding Conductor	239
352.60 Equipment Grounding Conductor.....	217		
Article 356—Liquidtight Flexible Nonmetallic Conduit (Type LFNC).....	219	Article 410—Luminaires, Lampholders, and Lamps.....	241
356.1 Scope	219	Part I. General	241
356.2 Definition.....	219	410.1 Scope	241
356.60 Equipment Grounding Conductor.....	219	410.30 Supports	241
Part V. Grounding (Bonding).....	242		
410.40 General.....	242	Part XVI. Special Provisions for Horticultural Lighting Equipment	242
410.44 Equipment Grounding Conductor.....	242	410.182 Grounding	242
410.46 Equipment Grounding Conductor Attachment	242		
Article 358—Electrical Metallic Tubing (Type EMT).....	221		
358.1 Scope	221		
358.2 Definition.....	221		
358.42 Couplings and Connectors	221		
358.60 Equipment Grounding Conductor.....	222		
Part XIX. Special Provisions for Horticultural Lighting Equipment	242		
410.182 Grounding	242		
Article 362—Electrical Nonmetallic Tubing (Type ENT).....	223	Article 440—Air-Conditioning and Refrigeration Equipment	243
362.1 Scope	223	440.1 Scope	243
362.2 Definition.....	223	440.9 Grounding and Bonding.....	243
362.60 Equipment Grounding Conductor	223		

Article 450—Transformers	245	Article 555—Marinas, Boatyards, and Docking Facilities	271
450.1 Scope	245	555.1 Scope	271
450.10 Grounding and Bonding.....	245	555.13 Bonding of Non-Current-Carrying Metal Parts.....	271
Chapter 4—Practice Questions.....	247	555.37 Equipment Grounding Conductor.....	271
CHAPTER 5—SPECIAL OCCUPANCIES 251		Chapter 5—Practice Questions..... 273	
Article 501—Class I Hazardous (Classified) Locations.....	253	CHAPTER 6—SPECIAL EQUIPMENT 277	
Part I. General	253	Article 600—Electric Signs and Outline Lighting	279
501.1 Scope	253	600.1 Scope	279
501.30 Grounding and Bonding.....	253	600.7 Grounding and Bonding.....	280
Article 502—Class II Hazardous (Classified) Locations.....	255	Article 645—Information Technology Equipment	283
502.1 Scope	255	645.1 Scope	283
502.30 Grounding and Bonding.....	255	645.15 Equipment Grounding and Bonding.....	283
Article 503—Class III Hazardous (Classified) Locations.....	257	Article 680—Swimming Pools, Spas, Hot Tubs, Fountains, and Similar Installations	285
503.1 Scope	257	Part I. General Requirements for Pools, Spas, Hot Tubs, and Fountains	285
503.30 Grounding and Bonding.....	257	680.1 Scope	285
Article 517—Health Care Facilities	259	680.2 Definitions	285
517.1 Scope	259	680.6 Bonding and Equipment Grounding	289
517.2 Definitions	259	680.7 Bonding and Equipment Grounding Terminals	289
517.12 Wiring Methods	260	Part II. Permanently Installed Pools	289
517.13 Equipment Grounding Conductor for Receptacles and Fixed Electrical Equipment in Patient Care Spaces.....	260	680.21 Pool Motors.....	289
517.16 Isolated Ground Receptacles.....	263	680.23 Underwater Pool Luminaires	290
Article 525—Carnivals, Circuses, Fairs, and Similar Events	265	680.24 Junction Box, Transformer, or GFCI Enclosure	291
525.1 Scope	265	680.25 Feeders	291
525.31 Equipment Grounding.....	265	680.26 Equipotential Bonding	291
525.32 Portable Equipment Grounding Conductor Continuity.....	265	Part IV. Spas, Hot Tubs, and Permanently Installed Immersion Pools	296
Article 547—Agricultural Buildings	267	680.40 General	296
547.1 Scope	267	680.42 Outdoor Installations	296
547.2 Definitions	267	680.43 Indoor Installations	296
547.5 Wiring Methods	268	Part V. Fountains	296
547.10 Equipotential Planes	269	680.50 General	296
		680.54 Connection to an Equipment Grounding Conductor.....	296
		680.55 Methods of Equipment Grounding	297
		Part VII. Hydromassage Bathtubs	297
		680.70 General	297
		680.74 Equipotential Bonding	297
		Part VIII. Electrically Powered Pool Lifts	298
		680.80 General	298
		680.83 Bonding	298

Article 690—Solar Photovoltaic (PV) Systems	299
Part I. General	299
690.1 Scope	299
690.2 Definitions	300
Part IV. Wiring Methods and Materials	300
690.31 Wiring Methods	300
Part V. Grounding and Bonding	301
690.43 Equipment Grounding and Bonding	301
690.45 Size of Equipment Grounding Conductors	303
690.47 Grounding Electrode System	303
Chapter 6—Practice Questions	305
CHAPTER 8—COMMUNICATIONS SYSTEMS	309
Article 800—General Requirements for Communications Systems	311
Part I. General	311
800.1 Scope	311
800.100 Cable and Primary Protector Bonding and Grounding	311
800.180 Grounding Devices	314
Article 810—Radio and Television Antenna Equipment	315
810.1 Scope	315
810.4 Community Television Antenna	315
810.6 Antenna Lead-In Protectors	316
810.7 Grounding Devices	316
810.15 Metal Antenna Supports—Grounding	316
810.20 Antenna Discharge Unit	317
810.21 Bonding Conductor and Grounding Electrode Conductors	317
Part III. Amateur and Citizen Band Transmitting and Receiving Stations—Antenna Systems	319
810.57 Antenna Discharge Units—Transmitting Stations	319
810.58 Bonding Conductors and Grounding Electrode Conductors—Amateur and Citizen Band Transmitting and Receiving Stations	319
Article 820—Community Antenna Television (CATV) and Radio Distribution Systems (Coaxial Cable)	321
Part I. General	321
820.1 Scope	321
Part III. Protection	321
820.93 Grounding of the Outer Conductive Shield of Coaxial Cables	321
Part IV. Grounding Methods	322
820.100 Bonding and Grounding Methods	322
Chapter 8—Practice Questions	323
Final Exam A—Section II Straight Order	325
Final Exam B—Section II Random Order	335
INDEX	345
About the Author	349
About the Illustrator	350
About the Mike Holt Team	351