

TABLE OF CONTENTS

About This Textbook	xi	110.11 Deteriorating Agents	38
About the National Electrical Code	xv	110.12 Mechanical Execution of Work	38
About the Author	xx	110.13 Mounting and Cooling of Equipment	40
About the Illustrator	xxi	110.14 Conductor Termination and Splicing	40
About the Team	xxii	110.16 Arc-Flash Hazard Warning	46
Article 90—Introduction to the National Electrical Code	1	110.21 Markings	46
90.1 Purpose of the <i>NEC</i>	2	110.22 Identification of Disconnecting Means	47
90.2 Scope of the <i>NEC</i>	3	110.25 Lockable Disconnecting Means	47
90.3 <i>Code Arrangement</i>	4	110.26 Spaces About Electrical Equipment	48
90.4 Enforcement	5	110.27 Guarding	56
90.5 Mandatory Requirements and Explanatory Material	6	110.28 Enclosure Types	57
90.6 Formal Interpretations	7	Chapter 1 Practice Questions	58
90.7 Examination of Equipment for Product Safety	7		
90.9 Units of Measurement	7		
Article 90 Practice Questions	8		
CHAPTER 1—GENERAL	11		
Article 100—Definitions	13		
Article 110—Requirements for Electrical Installations	33		
110.1 Scope	33	Article 230—Services	77
110.2 Approval of Conductors and Equipment	33	230.1 Scope	78
110.3 Examination, Identification, Installation, and Use of Equipment	34	230.40 Number of Service-Entrance Conductor Sets	78
110.5 Copper Conductors	35	230.43 Wiring Methods	78
110.6 Conductor Sizes	35	230.46 Spliced Conductors	79
110.7 Wiring Integrity	35	230.66 Listed as Suitable for Service Equipment	79
110.8 Suitable Wiring Methods	36	230.70 Disconnect Requirements	80
110.9 Interrupting Protection Rating	36	230.71 Number of Disconnects	81
110.10 Circuit Impedance, Short-Circuit Current Rating, and Other Characteristics	37	230.72 Grouping of Disconnects	82
		230.76 Manual or Power Operated	82
		230.77 Indicating	83
		230.81 Connection to Terminals	83
		230.82 Connected on Supply Side of the Service Disconnect	83
		230.90 Overload Protection Required	84
		230.91 Location of Overcurrent Protection	84

Table of Contents

Article 240—Overcurrent Protection.....	85
240.1 Scope.....	86
240.2 Definitions	86
240.4 Protection of Conductors	87
240.6 Standard Ampere Ratings.....	88
240.10 Supplementary Overcurrent Protection	89
240.15 Ungrounded Conductors	89
240.21 Overcurrent Protection Location in Circuit.....	89
240.24 Location of Overcurrent Devices.....	92
240.32 Damp or Wet Locations	95
240.33 Vertical Position.....	95
240.60 General.....	95
240.61 Classification.....	96
240.80 Method of Operation.....	96
240.81 Indicating	96
240.82 Nontamperable.....	97
240.83 Markings	97
Article 250—Grounding and Bonding	99
Part I. General	99
250.1 Scope	99
250.4 General Requirements for Grounding and Bonding	99
250.8 Termination of Grounding and Bonding Conductors.....	102
250.10 Protection of Fittings.....	103
250.12 Clean Surfaces	103
Part II. System Grounding and Bonding	104
250.24 Service Equipment—Grounding and Bonding.....	104
250.30 Separately Derived Systems (Transformers)— Grounding and Bonding	108
Part III. Grounding Electrode System and Grounding Electrode Conductor.....	113
250.50 Grounding Electrode System.....	113
250.52 Grounding Electrode Types	114
250.53 Grounding Electrode Installation Requirements.....	117
250.54 Auxiliary Grounding Electrodes	121
250.62 Grounding Electrode Conductor	121
250.64 Grounding Electrode Conductor Installation	122
250.66 Sizing AC Grounding Electrode Conductor.....	125
250.68 Termination to the Grounding Electrode	126
250.70 Grounding Electrode Conductor Termination Fittings	128
Part IV. Grounding Enclosure, Raceway, and Service Cable Connections.....	128
250.86 Other Enclosures	128
Part V. Bonding	128
250.90 General.....	128
250.92 Bonding Equipment for Services	128
250.96 Bonding Other Enclosures	131
250.97 Bonding Metal Parts Containing Circuits over 150V to Ground	131
250.102 Bonding Conductors and Jumpers.....	132
Part VI. Equipment Grounding and Equipment Grounding Conductors	134
250.112 Specific Equipment Fastened in Place or Connected by Permanent Wiring Methods	134
250.114 Cord-and-Plug-Connected Equipment	134
250.118 Types of Equipment Grounding Conductors	134
250.119 Identification of Equipment Grounding Conductors	138
250.120 Equipment Grounding Conductor Installation	139
250.122 Sizing Equipment Grounding Conductor.....	140
Part VII. Methods of Equipment Grounding	141
250.134 Equipment Connected by Permanent Wiring Methods	141
250.136 Equipment Considered Grounded	141
250.138 Cord-and-Plug-Connected Equipment	142
250.142 Use of Neutral Conductor for Equipment Grounding	142
250.148 Continuity and Attachment of Equipment Grounding Conductors in Metal Boxes	142
Part VIII. Direct-Current Systems	143
250.166 Sizing Grounding Electrode Conductor.....	143
Chapter 2 Practice Questions	144
CHAPTER 3—WIRING METHODS AND MATERIALS	163
Article 300—General Requirements for Wiring Methods and Materials	167
300.1 Scope	167
300.3 Conductors	168
300.4 Protection Against Physical Damage.....	169

300.5	Underground Installations.....	172
300.6	Protection Against Corrosion and Deterioration.....	177
300.7	Raceways Exposed to Different Temperatures	179
300.8	Not Permitted in Raceways.....	180
300.9	Raceways in Wet Locations Above Grade.....	180
300.10	Electrical Continuity.....	181
300.12	Mechanical Continuity	181
300.13	Splices and Pigtails	182
300.14	Length of Free Conductors	182
300.15	Boxes or Conduit Bodies.....	183
300.17	Raceway Sizing	184
300.18	Inserting Conductors in Raceways.....	186
300.19	Supporting Conductors in Vertical Raceways	186
300.20	Induced Currents in Ferrous Metal Enclosures and Raceways.....	187
300.21	Spread of Fire or Products of Combustion.....	188
300.22	Wiring in Ducts Not for Air Handling, Fabricated Ducts for Environmental Air, and Other Spaces for Environmental Air (Plenums).....	189
300.23	Panels Designed to Allow Access.....	191
Article 310—Conductors for General Wiring.....		193
310.1	Scope.....	194
310.10	Uses Permitted	194
310.15	Conductor Ampacity	197
310.104	Conductor Construction and Application	202
310.106	Conductors.....	203
310.110	Conductor Identification.....	203
Article 312—Cabinets.....		205
312.1	Scope.....	205
312.2	Damp or Wet Locations	206
312.3	Installed in Walls.....	206
312.4	Repairing Gaps.....	206
312.5	Enclosures.....	206
312.6	Deflection of Conductors	208
312.8	Cabinets With Splices, Taps, and Feed-Through Conductors.....	208
Article 314—Outlet, Device, Pull and Junction Boxes; Conduit Bodies; and Handhole Enclosures... 211		211
314.1	Scope.....	211
314.3	Nonmetallic Boxes.....	211
314.4	Metal Boxes	212
314.15	Damp or Wet Locations	212
314.17	Conductors That Enter Boxes or Conduit Bodies	212
314.23	Support of Boxes and Conduit Bodies	213
314.28	Boxes and Conduit Bodies for Conductors 4 AWG and Larger.....	214
314.29	Wiring to be Accessible	217
314.30	Handhole Enclosures	218
Article 320—Armored Cable (Type AC).....		219
320.1	Scope.....	219
320.2	Definition.....	219
320.10	Uses Permitted	220
320.12	Uses Not Permitted.....	220
320.15	Exposed Work.....	220
320.17	Through or Parallel to Framing Members.....	220
320.23	In Accessible Attics or Roof Spaces	221
320.24	Bends.....	221
320.30	Securing and Supporting	221
320.40	Boxes and Fittings	222
320.80	Conductor Ampacity	222
320.100	Construction	223
320.108	Equipment Grounding Conductor	223
Article 330—Metal-Clad Cable (Type MC).....		225
330.1	Scope.....	225
330.2	Definition.....	225
330.10	Uses Permitted	226
330.12	Uses Not Permitted.....	227
330.17	Through or Parallel to Framing Members.....	227
330.23	In Accessible Attics or Roof Spaces	227
330.24	Bends.....	227
330.30	Securing and Supporting	228
330.40	Fittings	228
330.80	Conductor Ampacities.....	229
330.108	Equipment Grounding Conductor	229
Article 338—Service-Entrance Cable (Types SE and USE).....		231
338.1	Scope.....	231
338.2	Definitions	231
338.10	Uses Permitted	232
338.12	Uses Not Permitted.....	232
338.24	Bends.....	233

Article 340—Underground Feeder and Branch-Circuit Cable (Type UF)	235	Article 348—Flexible Metal Conduit (Type FMC)	249
340.1 Scope	235	348.1 Scope	249
340.2 Definition	235	348.2 Definition	249
340.6 Listing Requirements	236	348.6 Listing Requirements	249
340.10 Uses Permitted	236	348.10 Uses Permitted	249
340.12 Uses Not Permitted	236	348.12 Uses Not Permitted	250
340.24 Bends	236	348.20 Trade Size	250
340.80 Ampacity	236	348.22 Number of Conductors	250
340.112 Insulation	236	348.24 Bends	251
Article 342—Intermediate Metal Conduit (Type IMC)	237	348.26 Number of Bends (360°)	251
342.1 Scope	237	348.28 Trimming	251
342.2 Definition	237	348.30 Securing and Supporting	251
342.6 Listing Requirements	237	348.42 Fittings	252
342.10 Uses Permitted	238	348.60 Grounding and Bonding	252
342.14 Dissimilar Metals	238	Article 350—Liquidtight Flexible Metal Conduit (Type LFMC)	253
342.20 Trade Size	238	350.1 Scope	253
342.22 Number of Conductors	238	350.2 Definition	253
342.24 Bends	239	350.6 Listing Requirements	253
342.26 Number of Bends (360°)	239	350.10 Uses Permitted	253
342.28 Reaming	239	350.12 Uses Not Permitted	254
342.30 Securing and Supporting	239	350.20 Trade Size	254
342.42 Couplings and Connectors	241	350.22 Number of Conductors	254
342.46 Bushings	241	350.24 Bends	255
Article 344—Rigid Metal Conduit (Type RMC)	243	350.26 Number of Bends (360°)	255
344.1 Scope	243	350.30 Securing and Supporting	255
344.2 Definition	243	350.42 Fittings	256
344.6 Listing Requirements	244	350.60 Grounding and Bonding	256
344.10 Uses Permitted	244	Article 352—Rigid Polyvinyl Chloride Conduit (Type PVC)	257
344.14 Dissimilar Metals	244	352.1 Scope	257
344.20 Trade Size	244	352.2 Definition	257
344.22 Number of Conductors	245	352.10 Uses Permitted	258
344.24 Bends	245	352.12 Uses Not Permitted	259
344.26 Number of Bends (360°)	245	352.20 Trade Size	259
344.28 Reaming	245	352.22 Number of Conductors	259
344.30 Securing and Supporting	246	352.24 Bends	260
344.42 Couplings and Connectors	247	352.26 Number of Bends (360°)	260
344.46 Bushings	248	352.28 Trimming	260
344.100 Construction	248	352.30 Securing and Supporting	260
344.130 Standard Lengths	248	352.44 Expansion Fittings	261

352.46	Bushings	262	392.80	Ampacity of Conductors.....	279
352.48	Joints	263		Chapter 3 Practice Questions	280
352.60	Equipment Grounding Conductor	263			

Article 358—Electrical Metallic Tubing

	(Type EMT)	265
358.1	Scope.....	265
358.2	Definition.....	265
358.6	Listing Requirement	265
358.10	Uses Permitted	265
358.12	Uses Not Permitted.....	266
358.20	Trade Size	266
358.22	Number of Conductors.....	266
358.24	Bends.....	267
358.26	Number of Bends (360°).....	267
358.28	Reaming and Threading.....	267
358.30	Securing and Supporting	268
358.42	Couplings and Connectors.....	268
358.60	Grounding	269

Article 376—Metal Wireways

	271
376.1	Scope.....	271
376.2	Definition.....	271
376.10	Uses Permitted	272
376.12	Uses Not Permitted.....	272
376.21	Conductors—Maximum Size.....	272
376.22	Number of Conductors and Ampacity.....	272
376.23	Wireway Sizing.....	273
376.30	Supports.....	273
376.56	Splices, Taps, and Power Distribution Blocks	273

Article 392—Cable Trays

	275
392.1	Scope.....	275
392.2	Definition.....	275
392.10	Uses Permitted	276
392.12	Uses Not Permitted.....	277
392.18	Cable Tray Installations	277
392.20	Cable and Conductor Installation	278
392.22	Number of Conductors or Cables.....	278
392.30	Securing and Supporting	278
392.46	Bushed Raceway.....	278
392.56	Cable Splices.....	278
392.60	Equipment Grounding Conductor	278

CHAPTER 4—EQUIPMENT FOR GENERAL USE

	305
--	-------	-----

Article 404—Switches

	307
404.1	Scope	307
404.3	Switch Enclosures	307
404.4	Damp or Wet Locations	307
404.6	Position of Knife Switches	308
404.7	Indicating	308
404.8	Accessibility and Grouping.....	308
404.11	Circuit Breakers Used as Switches	309
404.12	Grounding of Enclosures.....	309
404.15	Switch Marking	309

Article 408—Switchboards and Panelboards

	311
408.1	Scope	311
408.4	Field Identification	311
408.5	Clearance for Conductors Entering Bus Enclosures.....	312
408.7	Unused Openings	312
408.36	Overcurrent Protection of Panelboards.....	313
408.37	Panelboards in Damp or Wet Locations.....	314
408.40	Equipment Grounding Conductor	314
408.41	Neutral Conductor Terminations.....	314

Article 450—Transformers

	315
450.1	Scope	315
450.3	Overcurrent Protection.....	315
450.9	Ventilation	316
450.10	Grounding and Bonding	316
450.11	Marking	317
450.13	Transformer Accessibility	317
450.14	Disconnecting Means	318

Article 480—Storage Batteries

	319
480.1	Scope	319
480.2	Definitions	320
480.3	Battery and Cell Terminations	321
480.4	Wiring and Equipment Supplied from Batteries.....	321

Table of Contents

480.8	Racks and Trays	321	Part VI. Marking	377	
480.9	Battery Locations	322	690.53	PV dc Power Source Label.....	377
Chapter 4 Practice Questions		324	690.54	Interactive System.....	378
CHAPTER 6—SPECIAL EQUIPMENT		329	690.55	PV Systems with Energy Storage.....	378
Article 690—Solar Photovoltaic (PV) Systems		331	690.56	Identification of Power Sources	378
Part I. General		331	Part VII. Connection to Other Sources	380	
690.1	Scope	331	690.60	Interactive Systems	380
690.2	Definitions	332	690.61	Loss of Interactive System Power	380
690.3	Other Articles.....	338	690.63	Unbalanced Interconnections.....	380
690.4	General Requirements	338	690.64	Point of Connection	380
690.5	Ground-Fault Protection.....	339	Part VIII. Storage Batteries	381	
690.6	Alternating-Current Modules	341	690.71	Storage Battery Installation	381
Part II. Circuit Requirements		341	690.72	Charge Control	382
690.7	Maximum Voltage	341	690.74	Battery Interconnections.....	382
690.8	Circuit Current and Circuit Sizing	344	Part X. Electric Vehicle Charging	382	
690.9	Overcurrent Protection.....	350	690.90	General	382
690.10	Stand-Alone Systems	354	690.91	Charging Equipment	382
690.11	Arc-Fault Circuit Protection (Direct Current)	355	Chapter 6 Practice Questions	383	
690.12	Rapid Shutdown of PV Systems on Buildings.....	355	CHAPTER 7—SPECIAL CONDITIONS	395	
Part III. Disconnecting Means		356	Article 705—Interconnected Electric Power Production Sources	397	
690.13	Building Supplied by a PV System	356	705.1	Scope	397
690.15	PV Equipment Disconnect.....	358	705.2	Definitions	398
690.16	Disconnecting Means for Fuses	359	705.6	Qualified Persons.....	398
690.17	Disconnect Type (dc)	360	705.10	Directory of Power Sources	398
690.18	Installation and Service	362	705.12	Point of Connection	399
Part IV. Wiring Methods		363	705.31	Location of Overcurrent Protection	407
690.31	Wiring Methods	363	705.32	Ground-Fault Protection.....	408
690.33	Connectors	367	705.40	Loss of Primary Source	408
690.34	Access to Boxes	368	705.100	Voltage Unbalanced (Imbalanced) Interconnections.....	408
690.35	Ungrounded Systems	368	Chapter 7 Practice Questions	410	
Part V. Grounding		369	FINAL EXAM A FOR SOLAR PHOTOVOLTAIC SYSTEMS	413	
690.41	System Grounding	369	FINAL EXAM B FOR SOLAR PHOTOVOLTAIC SYSTEMS	423	
690.42	Point of Grounding Connection	370	INDEX	433	
690.43	Equipment Grounding (Bonding)	370			
690.45	Size of Equipment Grounding Conductors	372			
690.46	Array Equipment Grounding Conductors	373			
690.47	Grounding Electrode System.....	373			
690.48	Continuity of Equipment Grounding	377			
690.49	Continuity of System Grounding.....	377			